

How to load a new firmware on LS boards for CMSIS-DAP

1. Introduction	1
2. Get the CMSIS-DAP firmware.....	2
3. Prepare the LS board.....	2
4. Write CMSIS-DAP firmware on LS board	2
5. Windows mbed USB driver	2

Contents

1. Introduction

This document describes the steps required for updating to a new firmware on LS board for CMSIS-DAP.

This document includes the following sections:

- Get the CMSIS-DAP firmware.
- Prepare the LS board.
- Update CMSIS-DAP firmware.

2. Get the CMSIS-DAP firmware

Download the CMSIS-DAP firmware matching the target board from compass:

<http://compass.freescale.net/livelink/livelink?func=ll&objId=232410365&objAction=browse&viewType=1>. Location accessible from inside NXP network only.

Use the following table to find out which image fits the target board:

BOARD	CMSIS-DAP FIRMWARE
LS1012A-RDB	k22fx512_if_mbed.bin
LS1012A-FRDM	k20dx128_if_mbed.bin
LS1021A-TWR	k20dx128_if_mbed.bin
LS1021A-IOT	k22fx512_if_mbed.bin
LS1043A-RDB	k22fx512_if_mbed.bin
LS1046A-RDB	k22fx512_if_mbed.bin

3. Prepare the LS board

Plug in power to LS board. Hold down Reset button while plugging the PC USB cable into the CSAM USB connector on the board.

On Windows, the board will be mapped as a Mass Storage Device under a volume labelled 'BOOTLOADER'.

LED for MBED status will blink in green on the board to acknowledge it is in bootloader mode.

4. Write CMSIS-DAP firmware on LS board

1. Copy the binary downloaded in Chapter 2, into this new volume, 'BOOTLOADER'
2. Wait the binary copy to finish; LED for MBED status will blink with higher rate on finish;
3. Unplug the USB cable from the board, then plug it back in to power cycle the module
4. You are now ready to connect to your board via CodeWarrior

5. Windows mbed USB driver

As specified in board Quick Start Guide, for Windows, please verify that mbed USB driver is installed. Use <http://mbed.org/handbook/Windows-serial-configuration> for references.

How to Reach Us:

Home Page:
www.nxp.com

E-mail:
support@nxp.com

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

NXP reserves the right to make changes without further notice to any products herein. NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: nxp.com/SalesTermsandConditions.

NXP, the NXP logo, CodeWarrior, and QorIQ are trademarks of NXP B.V. All other product or service names are the property of their respective owners. ARM, Cortex and TrustZone are trademarks or registered trademarks of ARM Ltd or its subsidiaries in the EU and/or elsewhere. All rights reserved.

© 2016 NXP B.V.

12 May 2016

