

Getting Started with AUTOSAR MCAL

Steve Mihalik

Senior Field Application Engineer

October 2018 | AMF-AUT-T3380



SECURE CONNECTIONS
FOR A SMARTER WORLD

Abstract

This session is intended for engineers either getting started or are interested in seeing how to use AUTOSAR MCAL to generate and implement code.

“Hello world” level examples are presented using Tresos configuration tool to generate AUTOSAR defined structures.

These structures are combined with NXP written drivers and user code to build an application.

Agenda

- Introduction
- Recommended workflow
- Port module – Port pin configurations (GPIO)
- Dio module - Add Digital I/O to control GPIO
- Gpt module - General Purpose Timer (RTC)
- Interrupt Ap - Add Interrupt capability to GPT
- Reference: NXP AUTOSAR Installation

Introduction



NXP AUTOSAR Licensing Summary rev. Sept 07 2018

Feature		Eval-uation	DISM	Expired	Produc-tion ⁴
MCAL, OS	Latest updates ¹ for that version put in your NXP account	Yes	Yes	No	No
	Installation license for your current or new PC	Yes	Yes	No	Yes
	Generated code can be used by application code	Yes	Yes	Yes	Yes
Tresos	Version used for testing is in your account	Yes	Yes	Yes but ²	Yes
	Use license ³ put in your account (renewed quarterly)	Yes	Yes	No	Yes
	Generated code's configuration can be modified	Yes	Yes	No	Yes
Support	On-line support	No	Yes	No	No

¹ Updates include Hot Fixes & RTM releases for that version. New AUTOSAR versions, e.g., 4.2 to 4.3, require additional license

² You can still download Tresos from your account but not use it due to expired license.

³ Notes: 1.) Tresos license only works with NXP products.

2.) Tresos license for versions 17.0 or later is an “activation code”; earlier versions is a “license file”.

⁴ Production licenses for licensed version do not expire



Installation Process

- 1. Get AUTOSAR installation SW to your NXP account*
- 2. Download MCAL / OS installation SW from your NXP account*
- 3. Download, install / renew Tresos & license code or file*
- 4. Download, install make utility*
- 5. Install MCAL (and/or OS)*
- 6. Sample application installation & build configuration*
- 7. Additional SW: Compiler, Java*

Recommended workflow



Recommended Workflow

Windows:

* First time only

1. Duplicate & rename sample application's folder*

Tresos:

1. Close any previous projects (reduces risk of configuring module of wrong project)
2. Import (copy) sample application's Tresos project*
3. Rename project to same name as sample application's folder*
4. Load project's configuration
5. Sanity check: Generate and ensure no errors
6. Modify as desired
7. Generate

Windows:

1. Copy output (.c and .h files) from Tresos project's output folder to sample application's folder
2. Modify application code as desired
3. Build

Duplicate & Rename Sample Application

- Copy an MCAL sample application folder.
Examples:
MPC5748G_MCAL4_0_sample_ap_devkit
or

MPC574XG_MCAL4_0_RTM_1_0_4_Sample_Application_6M




- Paste

- Rename to

Calypso6M_MCAL4_0_sample_ap_devkit

- Note: slides show alternate name:

Calypso3M_MCAL_4_0_Sample_Ap



Importing Sample Application into Tresos

1. Start Tresos. Use 64 bit if there is an option and you have Windows 64 bit. (First time: click yes to create workspace directory)


File - Import - General - Existing Projects into Workspace -> Click Next

2. First time: Check “**Copy**” box to copy workspace from NXP folder to EB folder.)

3. **Browse** to root directory (**Tresos folder**). Example:



C:\NXP\AUTOSAR\MPC574XG_MCAL4_0_RTM_1_0_4\Calyпсо6M_sample_ap_devkit \Tresos

4. Click **OK** -> Click **Finish**




Suggestion: Rename Tresos Project


- Right click on project – Rename (optional).
- Enter new name. Example:
Calypso6M_MCAL4_0_sample_ap



Opening a Sample Application Project





- > Right click on **Calypso6M_sample_ap**
- > select **Load Configuration**
- > click OK
- > expand project to see modules in project



Code Generation



- Right Click on configuration (under project name) and select **Generate Project**



- Note: If there are generation errors be sure the Os module is disabled and not enabled to Generate. (Right click on configuration [PPC] & select Module Configs). Os modules requires AUTOSAR OS for this example.
- Click OK when done

Locate generated Tressos output files (to be copied to ap)



1. Right click on project
2. Select properties
3. Select Resource, & note Location



After generation, copy new generated files to application

- **Copy** include & src folders **from the EB Tresos** generated folder location:

- **Delete prior folders & paste new into application's cfg folder** (not tresos folder)
(May need to create cfg folder in application folder)



Build MCAL project – Windows Option

- If needed, update **launch.bat** as done previously with installation for path names and adding “pause” at end.
 - Example application folder path:
C:\NXP\AUTOSAR\MPC574XG_MCAL4_0_RTM_1_0_4\Calypso6M_sample_ap
- Build: Double click on **launch.bat** file in your application folder from Windows explorer.
 - If build aborts at adc.c (1st module in list), then the compiler path may be the problem. Verify the path in launch.bat. Make sure your compiler license is valid too.

Example sample application launch.bat paths

::TRESOS

SET TRESOS_DIR=C:\EB\tresos14_2_1

::GHS (recommend comp_201416 since MCAL and OS ver 4.0 were tested with it)

SET GHS_DIR=C:\ghs\comp_201714

::DIAB

::SET DIAB_DIR=C:/Tools/WindRiver/diab/5.9.4.8

::Path to the plugins folder

SET PLUGINS_DIR=C:\NXP\AUTOSAR\MPC574XG_MCAL4_0_RTM_1_0_4\eclipse\plugins

SET MAKE_DIR=C:\gnuwin32

::SSC is required when OS is used

::SSC can still be defined if OS is not installed or not defined at all

SET SSC_ROOT=C:\NXP\AUTOSAR\MPC574xG_AUTOSAR_OS_4_0_92_RTM_1_0_3

Tip: add “pause” to the last line in the launch.bat file


Build project –

- **launch.bat**

Method to clean project

- In the project's **bin directory**, select all files **except if there are debugger files like run.cmm or any other .cmm file** and then delete those selected files.

Example:



- If you do a clean of the project, be sure to rebuild by executing launch.bat to prepare for the next exercise, download and debug.

Port module



Port and Dio example: GPIO

A simple GPIO application will be created that reads a pushbutton switch and outputs its state to an LED. Overall summary:

- Tressos:
 - Port Module: Add two GPIO pin configurations for LED output and switch input on EVB (done)
 - Dio Module: Name the two port pins

- Application code:

- Code loop: read switch when write switch state to LED

- Ports to be used on MPC5748G Mother-Daughter EVB are:

- Switch 2: **PA2**
- LED 4: **PG5**

Table 20. User Pushbutton S

Switch	Number	MCU Pin
SW3	1	PA1
SW4	2	PA2
SW6	3	PA3

Table 23. User LEDs (DS2, DS3,

	Number	MCU Pin
DS2	1	PG2
DS3	2	PG3
DS7	3	PG4
DS8	4	PG5

Port APIs

void **Port_Init**(const Port_ConfigType* ConfigPtr)

void **Port_SetPinDirection**(Port_PinType Pin, Port_PinDirectionType Direction)

void **Port_RefreshPortDirection**(void)

void **Port_GetVersionInfo**(Std_VersionInfoType* versioninfo)

void **Port_SetPinMode**(Port_PinType Pin, Port_PinModeType Mode)

Mapping pins to Port module

- From the I/O spreadsheet attached to the MPC5748G reference manual, MSCR numbers and function's SSS values are listed for ports:

6	Port	LVDS Pair Port	SIUL MSCR#	MSCR SSS	Function	Modul	Descriptio	Direction	Very Stror
21	PA[2]		2	0000_0000	GPIO[2]	SIUL2		I/O	X
22	PA[2]			0000_0001	E0UC_2_G	EMIOS0		O	
23	PA[2]			0000_0010	E2UC_0_X	EMIOS2		O	
753	PG[5]		101	0000_0000	GPIO[101]	SIUL2		I/O	X
754	PG[5]			0000_0001	E1UC_14_H	EMIOS1		O	
755	PG[5]			0000_0010	E2UC_2_Y	EMIOS2		O	

- Example's GPIO pins:

Description	Use	Port and Channel (Used for <u>Dio port and channel identification</u>)	SIUL_MSCR# (Used for Port pin identification)
Switch2	GPIO input	PA2	2
LED4	GPIO output	PG5	101

Port Module Example Project Workflow

Use a minimal application to duplicate. Go up to Tresos Step 6. * First time only

1. Windows:

1. Duplicate & rename sample application's folder* to `Calypso6M_MCAL4_0_gpio_ap`

2. Tresos:

1. Close any previous projects (reduces risk of configuring module of wrong project)
2. Import (copy) mcu application's Tresos project* (Import application's **Tresos** folder). Example:
`C:\NXP\AUTOSAR\MPC574XG_MCAL4_0_RTM_1_0_4\Calypso6M_MCAL4_0_mcu\Tresos`
3. Rename project to `Calypso6M_mcal4_0_gpio_ap`
4. Load project's configuration
5. Sanity check: Generate and ensure no errors
6. Modify as desired
7. Generate

3. Windows:

1. Copy output (.c and .h files) from Tresos project's **output** folder to sample application's **cfg** folder
2. Modify application code as desired
3. Build

Summary 1: Remove PortPins except JTAG; add 2 GPIO

Port module

Tab: PortConfigSet

Index 0: PortConfigSet_0

Tab: PortContainer

Index 0: PortContainer_0

Tab: PortPin

Index n: PortPin names (remove all port pins except JTAG (DCI) pins, add 2 PortPins)

Index of 1st added PortPin


Tab: General (name LED4, PCR 101, output, GPIO mode, portpin high level)

Index of 2nd added PortPin

Tab: General (name Switch2, PCR 2, input, GPIO mode)

Port (1): Enable Port module



- Enable Port module (if not already enabled) for configuration in Tressos project:
 - Right click on Port module
 - Click on Enable



Port (2): Enable code generation

- Enable modules as needed that will be configured to generate code:

- Right click on PPC
- Select Module Configurations....
- In Generate column, check box for:
 - Port
- Click OK



Port (3): Select PortConfigSet 0 1

- Double click on Port module's configuration ("Port")
- Click on PortConfigSet tab



The screenshot shows the NXP IDE interface. On the left, the Project Explorer displays a tree view of the project structure. The 'Port' module is selected under the 'Mcu' component. A red arrow points from the 'Port' module in the Project Explorer to the 'Port' configuration window. The 'Port' configuration window has three tabs: 'General', 'PortConfigSet', and 'Published Information'. The 'PortConfigSet' tab is selected. The 'Config Variant' is set to 'VariantPostBuild'. The 'PortGeneral' section is expanded, showing the following configuration options:

Option	Icon	Checked	Icon	Option	Icon	Checked	Icon
Port Development Error Detect	X	✓	✎	Port SetPinDirection Api	X	✓	✎
Port SetPinMode Api	X	✓	✎	Port VersionInfo Api	X	✓	✎
Port SetPinMode Does Not Touch GPIO Levels	X	☐	✎	Port Enable User Mode Support	X	☐	↺

Port (4): Select PortConfigSet 0 2


- Double click on PortConfigSet's Index 0

- Click on PowerConfigSet_0's PortContainer tab




Port (5): In PortConfigSet 0 select PortContainer 0

- Double click PortConfigSet_0's Index 0



- Click on the PortPin tab



Port (6): Delete all current PortPins in PortContainer

- Select all Indices (in Index column) **EXCEPT JTAG**, and click **X** to remove all existing pins

PortContainer

@ 1


Name

Index	Name	PortPin ...	PortPin ...	PortPin O...	PortPin S...	PortPin ...	PortPin H...	PortPin D...	PortPin ...		
0	Adc_Pot	X	X	X	X	X	X	X	X	13	
1	DCI_TCK	X	X	X	X	X	X	X	X	16	
2	DCI_TDI	X	X	X	X	X	X	X	X	14	
3	DCI_TDO	X	X	X	X	X	X	X	X	15	
4	DCI_TMS	X	X	X	X	X	X	X	X	17	
5	DSPIO_IN	X	X	X	X	X	X	X	X	4	
6	DSPIO_OUT	X	X	X	X	X	X	X	X	3	
7	Icu_meas...	X	X	X	X	X	X	X	X	1	
8	Key1	X	X	X	X	X	X	X	X	6	
9	LIN1_RXD	X	X	X	X	X	X	X	X	5	
10	LIN1_TXD	X	X	X	X	X	X	X	X	2	
11	Led1_Pwm	X	X	X	X	X	X	X	X	11	
12	Led2	X	X	X	X	X	X	X	X	9	
13	Led3	X	X	X	X	X	X	X	X	10	
14	Led4	X	X	X	X	X	X	X	X	12	
15	UART_LIN2...	X	X	X	X	X	X	X	X	8	
16	UART_LIN2...	X	X	X	X	X	X	X	X	7	


JTAG
Port
Pins

Port (7): Add two PortPins

- Click + twice to add two new port pins
 - PortPin_0 and PortPin_1 are added



- Double click on Index of the first added PortPin to configure it



Port (8) Configure PortPin output

- Name: LED4
- PortPin ID: PortPin Ids are a unique number used to identify the port configuration
 - Click on the “Calculate Value” icon to automatically get a unique number.
- PortPinPcr: (SIUL_MSCR#) **101**
- PortPin Direction:
PORT_PIN_OUT
 - **_OUT** sets MSCR bits **IBE=0,OBE=1**
 - **_IN** sets MSCR bits **IBE =1, OBE =0**
 - **_Disabled** sets MSCR both **IBE,OBE=0**
- PortPin Mode: GPIO
- PortPin Level Value:
PORT_PIN_LEVEL_HIGH

The screenshot shows a configuration window for a PortPin. At the top, the 'Name' field is set to 'LED4'. Below this is a 'General' tab with various configuration options. Red arrows from the text on the left point to the following fields in the interface:

- Name***: LED4
- PortPin Id (1 -> 264)***: 5
- PortPinPcr (0 -> 263)***: 101
- PortPin Direction***: PORT_PIN_OUT
- PortPin Mode***: GPIO (with a dropdown menu open showing options like GPIO, EMIOS1_E1UC_14_H_OUT, etc.)
- PortPin Level Value***: PORT_PIN_LEVEL_HIGH

Port (9) Go back to prior container & select other port pin

- Navigate back a container by clicking on up arrow

The screenshot shows the PortPin configuration interface. The top window is titled "PortPin" and has a "Name*" field containing "LED4". A red arrow points to the "up" arrow icon in the top right corner. A tooltip "Navigate one container upward" is visible over this icon. Below this, a "PortContainer" window shows the "Name" field containing "PortContainer_0". At the bottom, a "General PortPin" window displays a table of port pins. A red arrow points to the row with index 5, "PortPin_1".

Index	Name	Po
0	DCI_TCK	<input type="checkbox"/>
1	DCI_TDI	<input type="checkbox"/>
2	DCI_TDO	<input type="checkbox"/>
3	DCI_TMS	<input type="checkbox"/>
4	LED4	<input type="checkbox"/>
5	PortPin_1	<input type="checkbox"/>

- Double click on other added PortPin's index to configure it

Port (10) Configure PortPin input

- Name: Switch2

- PortPin Id: Click on Calculate Value icon to get unique ID
- PortPinPcr: 2 (SIUL MSCR# Per ref. manual's signals spreadsheet)
- PortPin Direction: PORT_PIN_IN
- PortPin Mode: GPIO

PortPin

Switch2

General

PortPin Wpe*

PortPin Wps*

PortPin Ode*

PortPin Safe Mode*

PortPin Read Back*

PortPin HysteresisControl*

PortPin Direction Changeable*

PortPin Mode Changeable*

PortPin Id (1 -> 264)*

PortPinPcr (0 -> 255)*

PortPin Direction*

PortPin Initial Mode*


PortPin Mode*

PortPin Level Value*

PortPin Output Slew Rate*


Need help?

- Need help? Click on a configuration and see help box in workspace bottom right.




Port (11): There will be an error, like below.....

- Click in problems view window to expand the errors




- Note 2nd error has message port number of pins is out of range
- Click on 2nd error
- This brings up the Port Container window
 - Click the pencil then calculate icon for PortNumberOfPortPins
 - Double click to automatically get the proper #
- Click on each remaining error, then click on “Calculate Value” for that parameter



Port (12): Navigate back

- Go back to prior container




- Note PortPins at a glance (D by the box means default value) :

Index	Name	PortPin Wpe	PortPin Wps	PortPin Ode	PortPin Safe Mode	PortPin With Read Back	PortPin HysteresisControl
0	DCI_TCK	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
1	DCI_TDI	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	DCI_TDO	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	DCI_TMS	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4	LED4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5	Switch2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Port (13): Generate

- As a check, Generate project (right click on PPC, select Generate Project) to ensure no errors occurred.
- Click Save icon (disk icon in upper left)




S32K14x Port Mapping Example - 1

- From the Sample Application User Manual: Use highlighted port, with PCR ID 96

Table 4-1. PORT and DIO Modules - Pin Configuration and DioChannel Assignment

PortPin Name	Pin ID (PCR ID)	Pin Mode	Pin Direction	Pin Level	Connected HW	Channel Assignment
PortPin_PWM_Led1	96	FTM2_CH0	Out	Low	Blue Led	-
PortPin_Led2	111	GPIO	Out	High	Green Led	Dio_Led2


- Tressos Sample Application project: Open Port Module – Port Container tab – Double click on Index 0 (PortContainer_0) - click on PortPin tab –




Index	Name	PortPin Passive Filter Enable	PortPin Direction Changeable	PortPin Mode Changeable	PortPin Id	PortPin Pcr
1	PortPin_DBG_LED	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	13	64
16	PortPin_Led3	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	4	112
17	PortPin_PWM_Led1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	1	96
18	PortPin_UART1_RX	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	21	72

S32K14x Port Mapping Example - 2

- Double click on that port pin's index, 17



- Port pin parameters can be configured



The screenshot shows the 'PortPin' configuration window. The 'Name' field is set to 'PortPin_PWM_Led1'. The 'General' tab is active, showing various configuration options:

- PortPin Passive Filter Enable:
- PortPin Direction Changeable:
- PortPin Mode Changeable:
- PortPin Id: 1
- PortPin Pcr: 96
- PortPin Mode: FTM2_CH0
- PortPin DSE: High_drive_strength
- PortPin PE: PullDisabled
- PortPin PS: PullDown
- PortPin Direction: PORT_PIN_OUT
- PortPin Initial Mode: PORT_GPIO_MODE
- PortPin Level Value: PORT_PIN_LEVEL_HIGH

DIO module



DIO Example Introduction

- Dio module is used for controlling simple Digital I/O – General Purpose I/O
- This module adds to the prior PORT module example

Dio APIs

Dio_LevelType Dio_ReadChannel(Dio_ChannelType ChannelId)

void Dio_WriteChannel(Dio_ChannelType ChannelId, Dio_LevelType Level)

Dio_PortLevelType Dio_ReadPort(Dio_PortType PortId)

void Dio_WritePort(Dio_PortType PortId, Dio_PortLevelType Level)

Dio_PortLevelType Dio_ReadChannelGroup(const Dio_ChannelGroupType* ChannelGroupIdPtr)

void Dio_WriteChannelGroup(const Dio_ChannelGroupType* ChannelGroupIdPtr, Dio_PortLevelType Level)

void Dio_GetVersionInfo(Std_VersionInfoType* VersionInfo)

Dio_LevelType Dio_FlipChannel(Dio_ChannelType ChannelId)

Mapping pins to Dio modules

- From the I/O spreadsheet attached to the MPC5748G reference manual, MSCR numbers and function's SSS values are listed for ports:

	Port	LVDS Pair Port	SIUL MSCR#	MSCR SSS	Function	Modul	Descriptio	Direction	Very Stror
21	PA[2]		2	0000_0000	GPIO[2]	SIUL2		I/O	X
22	PA[2]			0000_0001	E0UC_2_G	EMIOS0		O	
23	PA[2]			0000_0010	E2UC_0_X	EMIOS2		O	
753	PG[5]		101	0000_0000	GPIO[101]	SIUL2		I/O	X
754	PG[5]			0000_0001	E1UC_14_H	EMIOS1		O	
755	PG[5]			0000_0010	E2UC_2_Y	EMIOS2		O	

- Example's GPIO pins:

Description	Use	Port and Channel (used for Dio port and channel identification)	SIUL_MSCR# (Used for <u>Port pin</u> identification)
Switch2	GPIO input	PA2	2
LED4	GPIO output	PG5	101

Summary: Remove Dio Ports; add 2 ports/channels

Dio module (DioPorts and DioChannels shown for Mother-Daughter EVB – add PA[2], PG[5])

Tab: DioConfig

Index 0: DioConfig_0

Tab: DioPort (remove all DioPorts; add 2 DioPorts)

Index of 1st added DioPort: DioPort_0

Tab: General (Name DioPA, Dio Port Id = 0)

Tab: DioChannel (Add channel)

Index 0: DioChannel_0

Tab: General (Name Switch2, Chan Id 2)

Index of 2nd added DioPort: DioPort_1

Tab: General (Name DioPG, Dio Port Id = 6)

Tab: DioChannel (Add channel)


Index 0: DioChannel_0 (Name LED4, Chan Id 5)

*DioPorts are
containers*



Dio (1): Enable module for configuration



- Note: Dio module enables writing to Power registers
- Right click on Dio module
- Click Enable to enable configuration



Dio (2): Enable code generation

- Enable modules that will be configured

- Right click on PPC
- Select Module Configurations....
- In Generate column, check box for:
 - Dio
- Click OK



Dio (3): Open Dio configuration



- Double click on Dio's configuration. Dio module's General settings

The screenshot displays the IDE interface for configuring the Dio module. On the left, the Project Explorer shows a tree view of the project structure. The 'Dio' module is selected under the 'PPC (PA, MPC574XG)' component. A red arrow points to the 'Dio' icon in the tree. The main window shows the 'Dio' configuration page with tabs for 'General', 'DioConfig', and 'Published Information'. The 'General' tab is active, showing 'DioGeneral' settings. A 'Config Variant' dropdown is set to 'VariantPreCompile'. Below, a list of settings is shown with checkboxes and edit icons.

Setting Name	Icon	Checked	Edit
Dio Development Error Detect	X	<input checked="" type="checkbox"/>	✎
Dio Reverse Port Bits	X	<input type="checkbox"/>	✎
Dio Read Zero For Undefined Port Pins	X	<input checked="" type="checkbox"/>	✎
Enable Dio User Mode Support	X	<input checked="" type="checkbox"/>	↺
Dio Version Info Api	X	<input checked="" type="checkbox"/>	✎
Dio Flip Channel Api	X	<input checked="" type="checkbox"/>	✎
Dio Masked Write Port Api	X	<input type="checkbox"/>	✎

Dio (4): Remove all Dio ports & channels

- Click on DioConfig tab
- Double click on Index 0 of DioConfig
- Select all indices (index 0 and 1)
- Click the red **X** to remove those elements



Dio (5): Add a DioPort

- Click on the green + to add a port

DioConfig

Name DioConfig_0

DioPort

DioPort*

Index

Name

Dio Po

Add new element with default values

- Double click on the new port's index

DioConfig

Name DioConfig_0

DioPort

DioPort*

Index

Name

Dio Port...

0

DioPort_0

0

Dio (6): Configure a DioPort - 1

- Click on **Dio Port Id (0 -> 16)***
- Note description for the Dio Port Id. The value corresponds to Port A, B, C, etc.

DioPort

Name*

General DioChannel DioChannelGroup

Dio Port Id (0 -> 16)*

Default

Error Log Problems View Description Information Errors

Last 1 entries (up to 100) warnings, errors (filtered out: infos)

Message

- ✘ Generation of project Calypso6M_mcal4_0_gpio_ap_devkitev has been

Name: DioPortId

Numeric identifier of the DIO port. Symbolic names will be generated for each port pin id for the pins which being used for configuration.


NOTE: Use the following values to configure different ports.

- PortA=0
- PortB=1
- PortC=2
- PortD=3
- PortE=4
- PortF=5
- PortG=6
- PortH=7
- PortI=8
- PortJ=9
- PortK=10
- PortL=11
- PortM=12
- PortN=13
- PortO=14
- PortP=15
- PortQ=16

Dio (7) Configure a DioPort - 2



Description	Use	SIUL_MSCR# (Used for <u>Port</u> pin identification)	Port and Channel (used for Dio port and channel <u>identification</u>)
Switch2	GPIO input	2	PA2
LED4	GPIO output	101	PG5

- Dio Port Id: **0** (for Port A)




Dio (8) Add channel to DioPort - 1

- Click on DioChannel tab
- Click on green + to add new DioChannel
- Double click on index 0 to configure the first channel



Dio (9) Add channel to DioPort - 2


- Name: Switch2
- Dio Channel Id: 2
- Now we have configured channel 2 on Port A.
- Click the up arrow to navigate one container upward



Description	Use	SIUL_MSCR# (Used for <u>Port pin identification</u>)	Port and Channel (used for <u>Dio port and channel identification</u>)
Switch2	GPIO input	2	PA2
LED4	GPIO output	101	PG5

Dio (10) Add additional port

- We are done configuring channels (pins) on Port A. Now we need to add Port G and then a channel on Port G.
- Click on the up arrow to navigate upward a container
- Click on the green + to add a new port.
- A new port with Index 1 is created
- Double click on Index 1 to configure the new port




Dio (11) Configure new port, add channel

- Configure Port:

- Name: DioPG
- Dio Port Id: 6 (for port G)

- Configure Channel:


- Click on DioChannel tab
- Click on + to add channel
- Double click on the channel's index to bring up its configuration



Dio (12) Channel configuration

DioChannel

- Name: LED4
- Dio Channel Id: 5
- Now we have configured channel 5 on Port G




Description	Use	SIUL_MSCR# (Used for <u>Port pin identification</u>)	Port and Channel (used for <u>Dio port and channel identification</u>)
Switch2	GPIO input	2	PA2
LED4	GPIO output	101	PG5

Dio (13): channel symbolic names


- AUTOSAR convention requires using the following name format.
- Format: ModulenameConf_Containername_channel name
- **Symbolic names here for coding are generated and placed in Dio_Cfg.h in folder c:\EB\tresos\workspace\your_project\output\include**
- **DEVKIT** EVB Example (0xa corresponds to MSCR10; 0x4c to MSCR76):

```
#define DioConf_DioChannel_LED4 ((uint16)0x0000aU)
#define DioConf_DioChannel_Switch2 ((uint16)0x00004cU)
```




Copy generated code to application

- **Copy** include & src folders from Tresos workspace project's **output** folder



- **Delete existing** include & src folder in application project's **cfg** folder



- **Paste** in new include & src folders to application project's **cfg** folder

Edit Modules file to add newly enabled modules

- In project's root directory (which has launch.bat):
 - Edit text file “Modules” to add Dio and Port.
(TIP: Add in alphabetical order – a good habit because it makes it easier to check)

```
# specify modules which will be compiled and linked  
MODULE_LIST := Base Det Dem Dio EcuM Mcu Port Rte
```

Add Dio code to main function in main.c ap's src folder:

Add global variable:

```
VAR(uint8, AUTOMATIC) Level_Switch2 =0;
```

Add code function to main before loop:

```
Port_Init(&PortConfigSet_0);
```

Add code inside forever loop:

```
/* Turn off (1) LED4 if Switch 2 is pressed (reads 1 if pressed)*/  
Level_Switch2 = Dio_ReadChannel((Dio_ChannelType)DioConf_DioChannel_Switch2);  
if (Level_Switch2 == 1) {  
    Dio_WriteChannel((Dio_ChannelType)DioConf_DioChannel_LED4, 1); /* Off */  
}  
else {  
    Dio_WriteChannel((Dio_ChannelType)DioConf_DioChannel_LED4, 0); /* On */  
}
```

Complete GPIO project

- Clean Project
- Run launch.bat
- Download to board
- Run program. Validate LED is on except when switch is pressed.

Review: MCAL Modules Used for GPIO

- **PORT**

- Configures port pins (SIUL2_MCSR and SIUL2_IMSR pad control register initializations)
- **Pin identification:** Done using Pin Configuration Register numbers (SIUL_MSCRx)
- Generated code will be put in Port_Init function (name is an AUTOSAR standard). User must call Port_Init

- **DIO**

- Used for reading and writing GPIO data
- Configures name to GPIO port pins (e.g. PA1, PA2, ..., PB1, PB2, etc.)
- **Pin identification:**
 - Dio Port Id number:** Corresponds to port's letter. (PortA=0, PortB=1, PortC=2, etc.)
 - Dio Channel Id number:** Corresponds to port Port pin's number (0, 1, 2,...)

- **References:**

- User Manual for Sample MCAL Application
- AUTOSAR MCAL Integration and User Manuals for:
 - PORT Driver
 - DIO (Digital I/O) Driver

<i>Driver</i>	<i>Name for a Port Pin</i>	<i>Name for Subset of Adjacent pins on one port</i>	<i>Name for a whole port</i>
DIO Driver	Channel	Channel Group	Port
PORT Driver	Port pin	--	Port

Gpt module



Gpt Example: Timer RTC with SXOSC Overview

Configurations:

- Mcu configurations
 - Set SOSC frequency
 - Enable SOSC
- Gpt configurations for RTC
 - Set prescaler, channel ID, channel (RTC), frequency
- Mcl
 - Enable Mcl (contains eMIOS which is needed for Gpt driver compilation.)

Code:

- Mcu_InitClock: enables SXOSC and other clocks
- GptStartTimer: code to start timer

Suggested Project Workflow

* First time only

Use again a minimal sample ap to duplicate. Go until Tressos Step 5.

1. Windows:3

1. Duplicate & rename Mcu application's folder to Calypso6M_mcal4_0_soxc_gpt_irq*

2. Tressos:

1. Close any previous projects (reduces risk of configuring module of wrong project)
2. Import (copy) application's Tressos project* (Import application's **Tressos** folder). Example:
`C:\NXP\AUTOSAR\MPC574XG_MCAL4_0_RTM_1_0_4\Calypso6M_mcu_ap\Tressos`
3. Rename project to Calypso6M_mcal4_0_sxosc_gpt_irq*
4. Load project's configuration
5. Sanity check: Generate and ensure no errors
6. Modify as desired
7. Generate

3. Windows:

1. Copy output (.c and .h files) from Tressos project's **output** folder to sample application's **cfg** folder
2. Modify application code as desired
3. Build

Timer Summary 1: Configure SXOSC

Mcu module

Tab: McuModuleConfiguration

Index 0: McuConfigPB_0

Tab: General (**Verify Slow Crystal Frequency = 32KHz**)

Tab: McuClockSettingConfig


Index 0: McuClockSettingConfig

Tab: General (**Enable SXOSC**)

Tab: McuSXOSC (**set SXOSC divider, etc.**)

Mcu (1): SXOSC - verify crystal frequency 1

- Double click Mcu driver configuration
- McuModuleConfiguration tab:
 - Double click on Index 0



The screenshot shows the 'Mcu' configuration window. The 'McuModuleConfiguration' tab is selected, indicated by a red arrow. Below the tabs, a table titled 'Multiple Configuration: McuModuleConfiguration' is displayed. The table has columns for 'Index', 'Name', and two 'Mcu Nu...' columns. The first row, with 'Index' 0, is highlighted in blue and has a mouse cursor over it, with a red arrow pointing to it. The 'Name' column for this row contains 'McuConf...'. The 'Mcu Nu...' columns contain the value '1'.

Index	Name	Mcu Nu...	Mcu Nu...	Fa
0	McuConf...	1	1	

Mcu (2): SXOSC - verify crystal frequency 2


- On the General tab, verify the Slow Crystal Frequency is 32767 (default).
 - This is the SXOSC crystal.

The screenshot shows the 'McuModuleConfiguration' interface for 'McuConfigPB_0'. The 'General' tab is active, displaying several configuration parameters. A red arrow points to the 'Slow Crystal Frequency [Hz]' field, which is set to 32767.0. Other parameters include 'Mcu Number of Mode Settings' (1), 'Mcu Number of RAM Sectors' (1), 'Reset Setting' (1), 'Fast Crystal Frequency [Hz]' (4.0E7), and 'Fast RC Frequency [Hz]' (1.6E7).


Parameter	Value
Mcu Number of Mode Settings (1 -> 255)	1
Mcu Number of RAM Sectors (1 -> 4294967295)	1
Reset Setting (1 -> 255)	1
Fast Crystal Frequency [Hz] (8000000 -> 40000000)	4.0E7
Slow Crystal Frequency [Hz] (1 -> 80000000)	32767.0
Fast RC Frequency [Hz] (1 -> 80000000)	1.6E7

Mcu (3): SXOSC - Enable

- Click on McuClockSettingConfig tab
- Double click on index 0 to open McuClockSettingConfig



- Scroll down to bottom right, click to enable SXOSC (if not enabled already)



Mcu (4): SXOSC - Set frequency, other parameters

- Click on McuSXOSC tab
 - Configure parameters as needed.
 - For this example, the default values are used so no changes are needed
 - Note other parameters
 - Note: You can configure the Mcu driver to not touch SXOSC at all using parameter SXOSC under MCU control
 - Similar capability exists for other Mcu resources

The screenshot displays the 'McuClockSettingConfig' configuration window. The 'McuSXOSC' tab is selected, and the 'McuSXOSC' sub-tab is active. The configuration parameters are as follows:

Parameter	Value	Control
SXOSC under MCU control	<input checked="" type="checkbox"/>	Oscillator start-up delay bypass
Auto level control	<input type="checkbox"/>	
EOCV (0 -> 255)	64	
SXOSC clock interrupt mask	<input type="checkbox"/>	
SXOSC Div (1 -> 32)	1	
SXOSC Output Value (1000 -> 35000)	32767.0	

Red arrows in the original image point to the 'McuSXOSC' tab and the 'SXOSC under MCU control' checkbox, and another red arrow points to the 'SXOSC Output Value' field.

Timer Summary 2: Create timer channel with RTC, SXOSC

Gpt module

Tab: GptChannelConfigSet

Index 0: GptChannelConfigSet_0

Tab: GptChannelConfiguration (delete current configurations, then add new one)

Index 0: GptChannel_0

Tab: General (rename channel to RtcTimer, GptHwCh = RTC, continuous



mode,

RTC clock source = SXOSC.

Note: GptChannelTickFrequency will be set/calculated later)


Gpt (1) - Enable Gpt, Mcl configuration and generation

- Right click on PPC
- Click on Module Configurations...
- Click both Enable and Generate to enable Gpt and Mcl (Micro Controller Library) module configurations and code generation.



Gpt (2) : Delete existing channels



- Click GptChannelConfigSet tab
- Double click on GptChannels's index 0
- Select all existing channels
- Click **X** to delete those unneeded channels



Gpt (3) - Add Gpt channel


- Add Channel: Click on Green +

- Double click on new channel's index to configure it




Gpt (4) – Configure Gpt channel - 1

- Name: RtcTimer



- GptHwChannel: Scroll down selections to enable and select RTC_0_CH_0



- Note some parameters have red boxes in front of them. This means the parameter is disabled.
- Those boxes will have to be checked to enable the parameter for configuration

Gpt (5) - Configure Gpt channel - ?

- GptChannelMode: choices are one shot or continuous. Select GPT_CH_MODE_CONTINUOUS
- GptChannelTickFrequency: this can be configured automatically later after configuring clock source references
- GptRtcChannelClkSrc:
 - Click red box to enable configuration
 - Select RTC_GPT_CLKSRC_SXOSC
- GptChannelPrescaler: See Description for prescaler value to divisor. Select "2" for divide the 32KHz SXOSC by 32.
- Other parameters can use default values



Timer Summary 3: Create SXOSC clock reference point

Mcu module

Tab: McuModuleConfiguration

Index 0: McuConfigPB_0

Tab: McuClockSettingConfig


Index 0: McuClockSettingConfig

Tab (far right): McuClockReferencePoint (add new reference point for SXOSC)


Index (new one): (name ClkRefPnt_SXOSC, freq. select = SXOSC, automatically calc ref pt value)

Mcu (1) – Configure clock reference point with SXOSC - 1

- To back to the Mcu configuration
- Click McuModuleConfiguration tab
- Double click index 0




- Select McuClockSettingConfig tab
- Double click Index 0



Mcu (2) - Configure clock reference point with SXOSC - 2

- Click on “10” which indicates there are 10 more tabs



- Select McuClockReferencePoint

Mcu (3) - Configure clock reference point with SXOSC - 3

- Click green + to add new clock reference point for SXOSC

- This will be needed for Gpt driver

- Double click on added reference point's index to configure it

The screenshot shows the IcuClockSettingConfig application interface. The main window displays the 'McuClockReferencePoint' configuration table. A red arrow points to the green plus icon in the toolbar, indicating the action to add a new reference point. The table lists various clock reference points with their indices, names, frequency selects, and reference point values.

Index	Name	Mcu Clock Frequency Select	Mcu Clock Reference P	Add new element with
0	ClkRefPnt_F40_CLK	F40		4.0E7
1	ClkRefPnt_F80_CLK	F80		8.0E7
2	ClkRefPnt_FS80_CLK	FS80		8.0E7
3	ClkRefPnt_FXOSC	FXOSC		4.0E7
4	ClkRefPnt_SYS_CLK	F160		1.6E8
5	ClkRefPnt_Wdg	SIRC		128000.0
6	McuClockReferencePoint_EMIO_0	CUSTOM		1000000.0
7	McuClockReferencePoint_0	F160		1.6E8

Mcu (4) - Configure clock reference point with SXOSC - 4


- Name: ClkRefPnt_SXOSC

- Mcu Clock Frequency Select: choose SXOSC

- Mcu Clock Reference Point Frequency: Double click on calculate value

- **Note:**

- Mcu module configures all clocks.
- Clock reference points are a mechanism to provide clock information from Mcu module to other modules.



Timer Summary 4: Configure a GptClockRefPt using RTC/SXOSC

Gpt module



Tab: GptClockReferencePoint

Index 0: GptClockReferencePoint_0

Tab: General (select GptClockReference = ClkRefPnt_SXOSC)

Gpt (1) – Config a Gpt clock reference point with SXOSC 1

- Go back to Gpt configuration
- If needed navigate to the top of the Gpt container
- Select tab GptClockReferencePoint
- Expand column widths to see all text
- Select GptClockReference of Index 0
 - Down arrow appears
- Click down arrow for GptClockReference options
- Select SXOSC



Gpt (2) - Config a Gpt clock reference point with SXOSC 2

- Expand Outline view in bottom left of screen, shown below
 - GptChannelConfigSet – GptChannel ConfigSet_0 – GptChannelConfiguration -RtcTimer
 - GptChannelSrcRef: ensure GptClockReferencePoint_0 is selected
 - Click the calculate for GptChannelTickFrequency then on the Calculate icon

The screenshot displays the configuration of a GPT channel in an IDE. The Project Explorer on the left shows the expanded GptChannelConfigSet_0 > GptChannelConfiguration > RtcTimer. The Outline view at the bottom left shows the configuration tree with GptChannelTickFrequency* and GptChannelClkSrcRef* highlighted. The main configuration window shows the RtcTimer configuration with fields for GptChannelId (0), GptHwChannel (RTC_0_CH_0), GptChannelMode (GPT_CH_MODE_CONTINUOUS), GptChannelTickFrequency (1000.0), and GptChannelClkSrcRef (/Gpt/Gpt/GptDriverConfiguration/GptClockReferencePoint_0). A red arrow points from the GptChannelClkSrcRef field to the GptChannelClkSrcRef* entry in the Outline view.

Generate

- Generate to check for errors
- Click on **Problems View** tab
- Click on **Errors** to expand it
- Click on **Calypso6M_...** to expand it
- Right click on expanded error, **Invalid value...**, select **Details**
- Details window pops up: details say the maximum count is other than the 65535 value currently entered.
 - Details alternative: See Description window for error information
- Enter new value of 429....
- Generate and there should not be errors.

The screenshot displays a software configuration interface with several panels. On the left, a tree view shows configuration nodes like 'GptChannelMode', 'GptChannelTickFrequency', and 'GptChannelClkSrcRef'. On the right, a table lists parameters such as 'GPT_CH_MODE_CONTINU...', '1000.0', '/Gpt/Gpt/GptDriverConfig...', 'RTC_GPT_CLKSRC_SXOSC', 'GPT_STM_SYSTEMCLOCK', '2', '1', and '65535'. A 'Problems View Entry Details' dialog box is open, showing an error with Code 1019, Severity Error, and a message: 'Invalid value for node "/>

Parameter	Value
GPT_CH_MODE_CONTINU...	1000.0
GPT_STM_SYSTEMCLOCK	2
RTC_GPT_CLKSRC_SXOSC	1
GPT_STM_SYSTEMCLOCK	65535

The 'Problems View Entry Details' dialog box contains the following information:

- Code: 1019
- Severity: Error
- Project name: Calypso6M_mcal4_0_soxc_gpt_irq
- Path: /AUTOSAR/TOP-LEVEL-PACKAGES/Gpt/ELEMENTS/Gpt/GptChan
- Detailed Message: Invalid value for node "/>

Message	Code	Severity	Path
Calypso6M_mcal4_0_soxc_gpt_irq(1)	1019	Error	/AUTOSAR/TOP-LEVEL-PACKAG...

The context menu for the error entry includes the following options:

 - Copy
 - Export Log...
 - Expand All
 - Collapse All
 - Details...

Modules– Add new modules to be built to ap's list

- If present, remove Gio and Port modules (used in prior project)
- Add Gpt and Mcl (GPT requires Mcl to build) modules which will be compiled and linked. In Modules file of application's root folder:

```
MODULE_LIST := Base Det Dem EcuM Gpt Mcl Mcu Rte
```


SXOSC Code

- SXOSC and other clocks are already enabled by function `Mcu_InitClock`

- To get the timer to run, two functions must be added to main:

```
Gpt_Init(&GptChannelConfigSet_0);
```

```
Gpt_StartTimer(GptConf_GptChannelConfiguration_RtcTimer, 512 - 1);
```

- The 512-1 value is the timeout value until the flag is set.
- Application code can only basically read the timer value.
- Next section will show how to use the timer as an interrupt.

Clean, build, download, debug

- Run program and verify RTC increments

Interrupt Ap



Introduction

- This project adds to the previous Calypso6M_MCAL4_0_sxosc_rtc_irq project.
 - Same Tresos workspace is used (no need to import)
 - Same application folder is used

Enable Timer (RTC) interrupt



Enable Timer Interrupt (RTC) Example Overview

Configuration:


- Add GPT channel (**done**)
- Configure GPT channel for RTC_0_CH_0 and set other parameters for this channel (**done**)
 - MCAL supports API wakeup only, not RTC wakeup
- **Configure (name) notification function** (to be executed in ISR between prologue and epilogue)
- Enable the GPT channel in GptHwConfiguration (**Only required for MCAL 4.2 and later**)

Code:

- **Install interrupt service routine** Gpt_RTC_0_Ch_0_ISR on vector 225
 - Vector_vle_mcal.s file: use name from GPT Integration Manual
- **Enable interrupt in initialization task** (if OS used then ISR needs to be configured in OS configuration)
- **If not done**, call Gpt_StartTimer() using either the timer's ID number or symbolic name
- **Write notification function (called by driver ISR) for interrupt** [see main.c]

Summary of MCAL interrupt steps

	Step	Where	Notes
Tresos	1	Name notification function	Module container. Example: <i>Gpt-GptChannelConfiguration-Channel's Index</i>
Code	2	Install provided ISR name at IRQ vector	Folder: toolchains File: vector_vle_mcal.s
	3	Enable interrupt: priority > 0, core#	File: your initialization code
	4	Enable notification	File: your initialization code
	5	Add notification function	File: your application code
			Notification function is user code
			Get ISR name and vector from module's integration manual
			Write IRQ vector's priority & core # (INTC_PSRx)
			Sets software flag to make notification function called in ISR
			MCAL driver will clear peripheral flag



Interrupt Summary: Name Notification for timer example

Gpt module


Tab: GptChannelConfigurationSet

Index 0: GptChannelConfigSet_0

Tab: GptChannelConfiguration

Index 0: RtcTimer

Tab: General (Name: RtcTimeoutNotification)



Gpt 2- Name notification 2

- Click on red box before GptNotification to enable naming notification
- Enter name for notification function (name will be used in your code):
RtcTimeoutNotification
 - Notification function will be called from the ISR.
 - Notification function is for user code in ISR
- Save
- Generate

The screenshot shows the 'GptChannelConfiguration' window with the 'General' tab selected. The 'Name*' field is set to 'RtcTimer'. The 'GptNotification*' checkbox is checked, and the text field next to it contains 'RtcTimeoutNotification'. A red arrow points to the 'GptNotification*' checkbox, and another red arrow points to the 'RtcTimeoutNotification' text field.


Property	Value
GptChannelId (0 -> 4294967295)	0
GptHwChannel	RTC_0_CH_0
GptChannelMode	GPT_CH_MODE_CONTINUOUS
GptChannelTickFrequency (0 -> 160000000)*	1000.0
GptChannelClkSrcRef*	/Gpt/Gpt/GptDriverConfiguration/GptClockReferencePoint_0
GptRtcChannelClkSrc	RTC_GPT_CLKSRC_SXOSC
GptStmChannelClkSrc	GPT_STM_SYSTEMCLOCK
GptChannelPrescaler (1 -> 256)	2
GptChannelPrescalerAlternate (1 -> 256)	1
GptChannelTickValueMax (65535 -> 4294967295)*	4294967295
GptFreezeEnable	<input checked="" type="checkbox"/>
GptNotification*	<input checked="" type="checkbox"/> RtcTimeoutNotification

Enable GPT + ISR channel

MCAL4.2 ONLY:

- GptHwConfiguration tab:
Check the RTC timer's boxes for:
 - GptIsrEnable
 - GptChannellsUsed
- Save
- Generate
 - Note: screenshot is from MCAL4.2. It is not present in MCAL4.0 since this is done automatically with that version.

Gpt



Name

General | GptChannelConfiguration | GptHwConfiguration | GptClockReferencePoint | Published Information

GptHwConfiguration

Index	Name	GPT Periph...	GptIsrEnable	GptChannellsUsed
34	GptHwConfiguration_34	PIT_0_CH_8	<input type="checkbox"/>	<input type="checkbox"/>
35	GptHwConfiguration_35	PIT_0_CH_9	<input type="checkbox"/>	<input type="checkbox"/>
36	GptHwConfiguration_36	PIT_0_CH_10	<input type="checkbox"/>	<input type="checkbox"/>
37	GptHwConfiguration_37	PIT_0_CH_11	<input type="checkbox"/>	<input type="checkbox"/>
38	GptHwConfiguration_38	PIT_0_CH_12	<input type="checkbox"/>	<input type="checkbox"/>
39	GptHwConfiguration_39	PIT_0_CH_13	<input type="checkbox"/>	<input type="checkbox"/>
40	GptHwConfiguration_40	PIT_0_CH_14	<input type="checkbox"/>	<input type="checkbox"/>
41	GptHwConfiguration_41	PIT_0_CH_15	<input type="checkbox"/>	<input type="checkbox"/>
42	GptHwConfiguration_42	STM_0_CH_0	<input type="checkbox"/>	<input type="checkbox"/>
43	GptHwConfiguration_43	STM_0_CH_1	<input type="checkbox"/>	<input type="checkbox"/>
44	GptHwConfiguration_44	STM_0_CH_2	<input type="checkbox"/>	<input type="checkbox"/>
45	GptHwConfiguration_45	STM_0_CH_3	<input type="checkbox"/>	<input type="checkbox"/>
46	GptHwConfiguration_46	STM_1_CH_0	<input type="checkbox"/>	<input type="checkbox"/>
47	GptHwConfiguration_47	STM_1_CH_1	<input type="checkbox"/>	<input type="checkbox"/>
48	GptHwConfiguration_48	STM_1_CH_2	<input type="checkbox"/>	<input type="checkbox"/>
49	GptHwConfiguration_49	STM_1_CH_3	<input type="checkbox"/>	<input type="checkbox"/>
50	GptHwConfiguration_50	STM_2_CH_0	<input type="checkbox"/>	<input type="checkbox"/>
51	GptHwConfiguration_51	STM_2_CH_1	<input type="checkbox"/>	<input type="checkbox"/>
52	GptHwConfiguration_52	STM_2_CH_2	<input type="checkbox"/>	<input type="checkbox"/>
53	GptHwConfiguration_53	STM_2_CH_3	<input type="checkbox"/>	<input type="checkbox"/>
54	GptHwConfiguration_54	RTC_0_CH_0	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Interrupt code (RTC)



Get ISR name and interrupt vector number

- See *Integration Manual* in MCAL's eclipse/plugins/module/doc folder.
- Example from MPC574xG MCAL integration manual:
C:\NXP\AUTOSAR\MPC574XG_MCAL4_2_RTM_1_0_0\eclipse\plugins\Gpt_TS_T2D35M10I0R0\doc

Table 5-1. GPT ISR's (continued)

ISR Name	Hardware interrupt vector
ISR(Gpt_STM_2_Ch_1_ISR)	45
ISR(Gpt_STM_2_Ch_2_ISR)	46
ISR(Gpt_STM_2_Ch_3_ISR)	47
For RTC	
ISR(Gpt_RTC_0_Ch_0_ISR)	225

Install interrupt service routine

- Edit `Vector_vle_mcal.s` file in the application's "toolchains" folder using integration manual's name and interrupt number:

```
-----  
# Gpt related  
  .globl Gpt_PIT_0_TIMER_0_ISR  
  .globl Gpt_PIT_0_TIMER_1_ISR  
  .globl Gpt_RTC_0_Ch_0_ISR
```

```
-----  
IRQ225:  
  e_b Gpt_RTC_0_Ch_0_ISR                                #interrupt 225  
  .align ALIGN_SIZE
```

Interrupt sequence (shown with RTC)

- RTC interrupt is recognized in hardware
- Execution starts at peripheral's vector (#225 for RTC)
- ISR for vector, **Gpt_RTC_0_Ch_0_ISR**, is executed
- Executes generated prologue
 - If notification is configured, then ISR will call notification function.
 - In this example **RtcTimeoutNotification** is has been configured
 - Notification function will include user application code, such as incrementing counter, writing outputs, etc.
 - Executes generated epilogue

Enable interrupt for RTC

- Example- `sample_app_mcal_initialization_task.c`
 - Enable core for interrupt and assign priority

```
FUNC (void, SAMPLE_APP_CODE) SampleApp_Int_Init(void)
{
    /* Setup all the needed interrupts(and their priorities) */
    #if (USE_GPT_MODULE==STD_ON)
        /* Gpt interrupts*/
        REG_WRITE16(INTC_PSR(225), 0x8006);
        /* Gpt_RTC_0_CH_0_ISR : Core 0, priority 6 */
    #endif
}
```

Enable Notification for ISR and Start Timer

- Add code to start RTC (32KHz divided by 32 here = 1KHz) timer. 2 second timeout.
- Example- [main.c](#) (RTC timer is index 2 in Gpt configuration)

```
void SampleApp_Int_Init(void);    /* Local function  
prototype*/
```

Add before endless loop in main:

```
Gpt_Init(&GptChannelConfigSet_0);  
SampleApp_Int_Init();           /* Call function to enable interrupts */  
Gpt_EnableNotification(GptConf_GptChannelConfiguration_RtcTimer);  
Gpt_StartTimer(GptConf_GptChannelConfiguration_RtcTimer, 2000-1);
```


Add notification function for RTC (executed after timeout)

- File `main.c` - define variable(s) for notification function:

```
/*=====
                                GLOBAL VARIABLES
=====*/
VAR(uint8, AUTOMATIC) GptRtcCounter = 0;
```

- Define notification function that will be called in ISR (for example, add to LOCAL FUNCTIONS):

```
FUNC (void, SAMPLE_APP_CODE) RtcTimeoutNotification(void)
{
    GptRtcCounter++;
}
```

Complete project

- If not done, **save and generate code in Tresos**
- **Copy include and src folders** from Tresos to application's cfg folder
- Clean
- Run launch.bat
- If no errors, download and run.
- Verify **GptRtcCounter** increments

Reference: NXP AUTOSAR Installation



1. Get AUTOSAR installation SW to your NXP account



1A. Get AUTOSAR installation SW from web to your NXP account




Get AUTOSAR installation SW from web to your account 1

- Go to nxp.com Click on desired product*. Example: MPC5748G:


1. Click on PRODUCTS
2. Click on POWER ARCH....
3. Click on MPC5xxx/55xx 32-bit MCUs

*Note The ISO26262 MCAL version is developed according the SEooC requirements of ISO26262. NXP supplies a FMEA and a Safety Manual for this MCAL. The Safety Manual will state the MCAL's ASIL level.



Get AUTOSAR installation SW from web to your account 2

- Click on MPC57xx



The screenshot shows the NXP website navigation menu and a product page. The navigation menu is located at the top and includes the following items: PRODUCTS, SOLUTIONS, SUPPORT, and ABOUT. Below the navigation menu, there is a breadcrumb trail: Home > Microcontrollers and Processors > Power Architecture® Processors > MPC5xxx/55xx 32-bit MCUs. The main content area is divided into two columns. The left column is a navigation menu with the following items: Microcontrollers and Processors, Arm®-Based Processors and MCUs, More Processors, Power Architecture® Processors, QorIQ Platforms, PowerQUICC Processors, MPC5xxx/55xx 32-bit MCUs (highlighted), Ultra-Reliable MPC57xx 32-bit Automotive & Industrial Microcontrollers (MCUs), Ultra-Reliable MPC56xx 32-bit Automotive and Industrial Microcontrollers (MCUs), MPC55xx MCUs, mobileGT® (51xx/52xx), 5xx Controllers, and Identification and Security. The right column is a product page for MPC5xxx MCUs. It features a large image of a car interior with the text "AUTOMOTIVE A 32-BIT MCUS" and "Based on Power Architecture® Technol". Below the image, there is a text block: "MPC5xxx MCUs offer scalable, highly int with a focus on quality and long-term re". At the bottom of the page, there is a "Products" section with a sub-section for "MPC57xx" which includes the text "Powertrain, Body Control, ADAS" and "Single to multicore Functional Safety complia". A red arrow points from the "MPC57xx" link in the navigation menu to the "MPC57xx" link in the product page.

Get AUTOSAR installation SW from web to your account 3

- Scroll down on next page
- Click MPC574xB-C-B
- Click on Software & Tools

MPC57xx Products

Product	Description
MPC577xK	32-bit MCU for ADAS Applications - PREPRODUCTION
MPC574xB-C-G	Ultra-Reliable MCUs for Automotive & Industrial Control and Gateway
MPC5746R	Automotive & Industrial Engine Management MCU
MPC574xD	Ultra-Reliable MPC574xD MCU for Automotive & Industrial Safety Applications



The screenshot shows the NXP website interface. At the top, there is a navigation bar with 'PRODUCTS', 'SOLUTIONS', 'SUPPORT', and 'ABOUT' tabs. Below this is a breadcrumb trail: 'Microco...' > 'Power A...' > 'MPC5xx...' > 'Ultra-Rel...' > 'MPC574xB-C-G'. The main heading is 'MPC574xB-C-G: Ultra-Reliable MCUs for Automotive & Industrial Control and Gateway'. Below the heading is a tabbed interface with 'Overview', 'Documentation', 'Software & Tools', 'Buy/Parametrics', and 'Package/Quality' tabs. A red arrow points to the 'Software & Tools' tab.

Get AUTOSAR installation SW from web to your account 4

1. Scroll down to AUTOSAR and click on desired Download
2. Sign in with name and password
 - If you do not have an account, register
 - NXP & new employees use NXP ID and NXP password
 - (Legacy Freescale employees use core ID and oneIT password)
3. Select desired product.
Depending on product age, a registration code may be needed to add installation software to your account. Contact local sales office if needed.

AUTOSAR (3)



MPC574xB-C-G Autosar 4.0 MCAL (QM)^(REV 1.0.x)

Autosar (Classic) v4.0 rev 3 microcontroller abstraction layer drivers for ADC, CAN, DIO, ETH, FLS, FR, GPT, ICU, LIN, MCU, PORT, PWM, SPI, WDG, plus additionally FEE and DMA driver. Tested with Green Hills MULTI, Wind River DIAB. Autosar configuration tool EB tresos Studio included, solely for use with drivers of this package. Conditions of use for this software and other general information about Autosar at www.autosar.org and at Autosar

ZIP 1 KB SW574XG-MCAL401E

2017-02-14 18:00:00

Download



MPC574xB-C-G Autosar 4.0 Operating System (QM)^(REV b4.0.88)

Download

Sign in

Email Address

nxa12345

Password

.....

Remember me [?](#)

1b. Get AUTOSAR installation SW from NXP sW marketing to your NXP account



Get AUTOSAR installation SW from marketing to your account


- Some new version of MCAL, OS are not on the NXP public web site
- Customers can request these newer versions by:
 - Create an account a nxp.com if they do not have one:
 - Go to www.nxp.com
 - Click on ACCOUNT in upper right corner
 - Click on REGISTER and fill in the fields
 - Provide their name(s), project, requested software (version and chip) to the local sales office
 - The sales representative will forward the request to NXP software marketing.
 - When approved, a registration code will be provided to customer(s). A code is good for one PC.

2. Download MCAL / OS installation from your NXP account



Download installation SW from your NXP account 1

- Sign in to your account at nxp.com
- Click on drop-down arrow next to your name, then click on “MY ACCOUNT”



- Click “Software Licensing and Support”
- **NOTE:** customers usually need a unique registration code to download a software product

A screenshot of the NXP website's 'My Account' page. The page features a navigation bar with 'PRODUCTS', 'SOLUTIONS', 'SUPPORT', and 'ABOUT' links. Below the navigation bar, the user is greeted with 'Welcome, Steve Mihalik' and 'You logged in at 01-09-2018 07:23:10 MST'. A notification banner states: 'NEW For the most up-to-date technical documents, select Documentation and Tools Updates below. The tool is updated daily and is searchable and sortable by type, revision date and product.' The main content area is divided into two columns. The left column is titled 'PROFILE' and includes links for 'Change My Password', 'Orders', 'Subscription Center', and 'Documentation and Tools Updates'. The right column is titled 'SECURE APPLICATIONS' and includes links for 'Cross Check - Part Finder With Pricing', 'Cross Check - Competitor Cross Reference', 'eCommerce', 'Compass Extranet', 'MCU Programming Center', 'Moderated Downloads', 'ROM Programming', 'Software Licensing and Support', 'My LPCXpresso activations', and 'NXP Training'. A red arrow points from the 'Software Licensing and Support' link in the left column to the 'Software Licensing and Support' link in the right column.

Download installation SW from your NXP account 2



- Click on desired category (the first time you will have only one category)
 - Example:
Automotive SW – Autosar MCAL

PRODUCTS APPLICATIONS SUPPORT

NXP > Software & Support > Product List

Software & Support

- Product List
- Product Search
- Order History
- Recent Product Releases
- Recent Updates

Licensing

- License Lists
- Offline Activation

Product List

Welcome to the premier delivery, update, and manage your rapidly changing software from a

To access an item, select a product below.

- [Automotive SW - Autosar MCAL](#)
- [Automotive SW - Autosar MCAL / ISO26262](#)
- [Automotive SW - Autosar OS](#)
- [Automotive SW - AUTOSAR](#)



Download installation SW from your NXP account 3



NXP > Software & Support > Product Information : Automotive SW - Autosar MCAL

- Click in software you want to download
- Example:
Automotive SW – Autosar MCAL
- Note: Register button is for customer

Software & Support

Product List

Product Search

Order History

Recent Product Releases

Recent Updates

Licensing

License Lists

Offline Activation

FAQ

Product Information

Automotive SW - Autosar MCAL

Your choice contains a suite of products. Please
To register a New Product please click on the button

Register

Automotive SW - Autosar MCAL

Automotive SW - Elektrobit Tresos Studio / Autosar



Download installation SW from your NXP account 4



PRODUCTS APPLICATIONS SUPPORT ABOUT

NXP > Software & Support > Product Information : Automotive SW - Autosar MCAL

Software & Support

- Product List
- Product Search
- Order History
- Recent Product Releases
- Recent Updates

Licensing

- License Lists
- Offline Activation

FAQ

- Download Help
- Table of Contents
- FAQs

Product Information

Automotive SW - Autosar MCAL

To register a New Product please click on the button below

Register

Current Previous

Version	Description
1.0.4	SW574XG-MCAL401-RTMC_SR-1.0.4
1.0.0	SW32K14-MCAL421-RTMC-1.0.0
0.4.0	SW32G17-MCAL422-EAR-0.4.0
1.0.0	SW567YK-MCAL401-RTMC-1.0.0



- Click on desired version. Examples – MCAL 4.0, MCAL 4.3:

Product Information

Automotive SW - Autosar MCAL

To register a New Product please click on the button below

Register

Current Previous

Version	Description
1.0.0_P2	SW574XG-MCAL431-RTMC_1.0.0_P2
1.0.0_P1	SW574XG-MCAL431-RTMC_1.0.0_P1
1.0.0	SW574XG-MCAL431-RTMC-1.0.0
1.0.5	SW574XG-MCAL401-RTMC_SR-1.0.5



Download installation SW from your NXP account 5

- Click on I Agree to SW terms and conditions



PRODUCTS

APPLICATIONS

SUPPORT

ABOUT

NXP > Software & Support > Software Terms and Conditions

Software & Support

Product List

Product Search

Order History

Recent Product Releases

Recent Updates

Licensing

License Lists

Offline Activation

FAQ

Download Help

Table of Contents

FAQs

Software Terms and Conditions

SW574XG-MCAL401-RTMC_SR-1.0.4

Please read the following agreement and click "I AGREE" a

NXP Automotive Software License Agreement v1.6

(System Agreement ID 21147)

IMPORTANT. Read the following NXP Software the "I Accept" button at the end of this page, you may then install the software.

NXP SOFTWARE LICENSE AGREEMENT

This is a legal agreement between you (either as

I Agree

Cancel

COMPANY PUBLIC | 120



Download installation SW from your NXP account 6

- Check boxes for software to download
 - Examples: MCAL4.0, MCAL 4.3
- Click Download Selected Files
- **Note:** some versions have “hot fixes” to enhance a version. Hot fixes are cumulative – only need to install the last one after installing the released SW. See hotfix’s release notes to see if there is any impact to your application.



PRODUCTS APPLICATIONS SUPPORT ABOUT

NXP > Software & Support > Automotive SW - Autosar MCAL > SW574XG-MCAL401-RTMC_SR

Software & Support

- Product List
- Product Search
- Order History
- Recent Product Releases
- Recent Updates

Licensing

- License Lists
- Offline Activation

FAQ

- Download Help
- Table of Contents
- FAQs

Product Download

SW574XG-MCAL401-RTMC_SR-1.0.4

Files License Keys Notes

Show All Files

<input type="checkbox"/>	+	File Description
<input type="checkbox"/>	+	MPC574XG_MCAL4.0_RTM_1.0.4_QualityPackage.
<input type="checkbox"/>	+	MPC574XG_MCAL40_RTM_104Report.html
<input checked="" type="checkbox"/>	+	MPC574XG_MCAL4_0_RTM_1_0_4.exe
<input checked="" type="checkbox"/>	+	MPC574XG_MCAL4_0_RTM_1_0_4_ReleaseNotes

Download Selected Files

SW574XG-MCAL431-RTMC-1.0.0

Files License Keys Notes

Show All Files



<input type="checkbox"/>	+	File Description
<input type="checkbox"/>	+	MPC574XG_MCAL4_2_RTM_1_0_0_Report.xlsx
<input checked="" type="checkbox"/>	+	MPC574XG_MCAL4_3_RTM_1_0_0.exe
<input type="checkbox"/>	+	MPC574XG_MCAL4_3_RTM_1_0_0_QualityPackage.zip
<input checked="" type="checkbox"/>	+	MPC574XG_MCAL4_3_RTM_1_0_0_ReleaseNotes.pdf
<input checked="" type="checkbox"/>	+	MPC574XG_MCAL4_3_RTM_1_0_0_Sample_App.exe
<input checked="" type="checkbox"/>	+	MPC574XG_MCAL4_3_RTM_1_0_0_Sample_App_ReleaseNotes.pdf
<input type="checkbox"/>	+	MPC574XG_MCAL4_3_RTM_HF1_1_0_0.exe
<input type="checkbox"/>	+	MPC574XG_MCAL4_3_RTM_HF1_1_0_0_ReleaseNotes.txt
<input type="checkbox"/>	+	MPC574XG_MCAL4_3_RTM_HF2_1_0_0.exe
<input type="checkbox"/>	+	MPC574XG_MCAL4_3_RTM_HF2_1_0_0_ReleaseNotes.txt

Download Selected Files



Download installation SW from your NXP account 7

- Select folder (create if needed) to download installation software and click OK.
This folder can be anywhere, e.g., when you later run the install software, you can choose a path for the actual software package.
- Download progress is shown
- Close window when download completes.



Download AUTOSAR OS if needed

- If you also received a license code for the OS, follow the same steps to download the OS
- **NOTE: You must install TRESOS before MCAL or OS!!**
- **You must find the Tresos version needed for your MCAL or OS. See release notes for MCAL or OS. Search for Tresos.**

3. Download, Install / renew Tresos




Tresos Versions

- The Tresos version used for testing an MCAL version is put in your NXP Account with your requested MCAL version.
- To determine or verify what Tresos version an MCAL used, search for “Tresos” in MCAL’s or OS’s Release notes. (Normally higher number versions will work fine.)

_ 2.4 Modules Configuration

Modules configuration were developed and tested using the Tresos Configuration Tool version "*EB tresos Studio 14.2.1 b140128-1223*"



- **INSTALLATION TIP:** When installing Tresos include the version number in the Tresos folder name. This prevents confusion when another Tresos version is installed for a different MCAL version. Example:

Tresos Licensing: License File vs Activation Code

- Tresos version requirements:
 - Tresos versions before 17.0.0 require Tresos license files –for older MCALs
 - Tresos versions 17.0.0 & after require Tresos activation codes –for newer MCALs

- Examples:



Tresos Version	Requirement	MCAL Version
14.2.1	License File	MPC574xG MCAL 4.0
21.0	Activation Code	MPC574xG MCAL 4.2
23.0	Activation Code	S32K14x MCAL 4.2
24.0	Activation Code	MPC574xG MCAL 4.3 S32K14x MCAL 4.3

- Tresos license codes & activation codes are good for one calendar quarter (3 months)
- If you have a valid license in your account, a new license file or activation code is automatically added to your account by the end of the quarter

3A. Download, Install / renew Tresos with activation code (versions 17 & after)



Install Tresos – Versions 17.0.0 and after (1 of 5)

- Go to Product Download for Tresos (example v21.0.0):
 - Sign in to your account at nxp.com
 - Click the following: Software Licensing and Support
 - Autosar SW – Autosar MCAL
 - Autosar SW – Elektrobit Tresos Studio / Autosar Configuration Tool
 - AUTOSAR Tresos Studio 21.0.0
 - I agree
- Select all files and download to any folder. **Be sure to use “Download Selected Files” which uses the Download Manager or else files will be compressed in the wrong format.**

Product Download

AUTOSAR Tresos Studio 21.0.0

Files License Keys Notes

Please use the following activation code to start your evaluation:
12/31/2017)

Show All Files

<input checked="" type="checkbox"/>	+	File Description	File Si
<input checked="" type="checkbox"/>	+	1.1_EB_tresos_installation_guide.pdf	
<input checked="" type="checkbox"/>	+	Documentation_Documentation_EBtresosStudio.uip	
<input checked="" type="checkbox"/>	+	EBtresosStudio_EBtresosStudio.uip	
<input checked="" type="checkbox"/>	+	EBtresosStudio_StudioVariantPlugin.uip	
<input checked="" type="checkbox"/>	+	EBtresosStudio_WibuKeyRuntime.uip	
<input checked="" type="checkbox"/>	+	EB_Client_License_Administrator_1_2_4_Setup.exe	
<input checked="" type="checkbox"/>	+	setup.exe	

Download Selected Files

Install Tresos – Versions 17.0.0 and after (2 of 5)

- Note the activation code will be needed in subsequent steps
 - Codes are updated every 3 months.
 - See “Files” tab of Product Download in your account.
 - Copy and paste Tresos activation code to some temporary location for use later.

AUTOSAR Tresos Studio 21.0.0

Files License Keys Notes


Please use the following activation code to start your evaluation: **6C30-2789-6217** (valid until 03/31/2017)

Show All Files

<input checked="" type="checkbox"/>	+	File Description	File Size	File Name
<input checked="" type="checkbox"/>	+	1.1_EB_tresos_installation_guide.pdf	2 MB	1.1_EB_tresos_installation_guid
<input checked="" type="checkbox"/>	+	Documentation_Documentation_EBtresosStudio.uip	29.7 MB	Documentation_Documentation
<input checked="" type="checkbox"/>	+	EBtresosStudio_EBtresosStudio.uip	211 MB	EBtresosStudio_EBtresosStudi
<input checked="" type="checkbox"/>	+	EBtresosStudio StudioVariantPlugin.uip	4.1 KB	EBtresosStudio StudioVariantF


Install Tresos – Versions 17.0.0 and after (3 of 5)

- Run **setup.exe** from the downloaded folder
- Choose unique folder (Tip: include Tresos version # in the name)
- Click Install



Install Tresos – Versions 17.0.0 and after (4 of 5)

- If EB Client License Administrator is not already on your PC, install it.
 - Look for the program in the Windows program menu
 - To install, start the EB Client Administrator setup program from your downloaded folder.
- Start EB Client Administrator program from Start menu
- If necessary, click Next to get thru dialog boxes until you get to **FlexLM License information**
 - Click Use License Activation Codes
 - Click Next



Install Tresos – Versions 17.0.0 and after (5 of 5)

- You will be prompted for one of the following dialog boxes:
 - Click Install
or
 - Enter Tresos activation code (stored earlier; see slide 2 of 5)
 - Click Activate (You must be on line to activate)



The screenshot shows the 'Elektrobit Client License Administration V1.2.4' window. At the top, there is a 'Licenses' table with columns: Product, Activation Code, Fulfillmen..., Trusted Status, Expire Date, Maintenance ..., and Activate... The table contains one row with 'NONE' in the Product column and 'permanent' in the Maintenance ... column. Below the table, there are two main sections: 'Offline Activation' and 'Online Activation'. The 'Offline Activation' section has buttons for 'Create Activation Request ...', 'Process Activation ...', and 'Create Return Request ...'. The 'Online Activation' section has an 'Activation Code' field containing 'AC5C-6C30-2789-6217', a 'Number of Licenses' field containing '1', and 'Activate' and 'Upgrade' buttons. A red arrow points from the 'Process Activation ...' button to the 'Activation Code' field, and another red arrow points from the 'Number of Licenses' field to the 'Activate' button. At the bottom, a 'Status' section shows the message 'INFO: Trusted Storage initialization done.'

Tresos is now activated

Tresos Activation Code Renewal 1

(For versions 17.0.0 and after)

- Every 3 months the Tresos activation codes expire
- Customers with an active MCAL license (such as DISM or evaluation), will automatically get a new activation code in their account.
- Obtaining new Tresos activation code (for Tresos 17.0.0 or later):
 1. Go to Tresos in your nxp account:
 - Sign in to your account at nxp.com
 - Click the following: Software Licensing and Support
 - Autosar SW – Autosar MCAL
 - Autosar SW – Elektrobit Tresos Studio / Autosar Configuration Tool
 2. Select the Tresos version for your MCAL or OS. Example:

Product Information

Automotive SW - Elektrobit Tresos S

To register a New Product please click on the button

Register

Current

Previous

Version	Description
24.0.1	AUTOSAR Tresos Studio 24.0.1
24.0.0	AUTOSAR Tresos Studio 24.0.0
23.0.0	AUTOSAR Tresos Studio 23.0.0
21.0.0	AUTOSAR Tresos Studio 21.0.0

Tresos Activation Code Renewal 2

(For versions 17.0.0 and after)

3. Agree to SW terms and conditions.

4. Copy activation code

Product Download

AUTOSAR Tresos Studio 21.0.0

Files License Keys Notes

Please use the following activation code to start your evaluation: C195-344A-C09/30/2018)

Software Terms and Conditions

AUTOSAR Tresos Studio 21.0.0

Please read the following agreement and click "I AGREE" at the bottom be

1.2 'AGREEMENT' means the QUOTATION as accepted by CUSTOMER and the annexes thereto, together with these EB T&C.

1.3 'BACKGROUND IP' means any software, hardware, documentation, materials, data, technology, information, know-how and INTELLECTUAL PROPERTY RIGHTS, in whatever form, that have been created or developed prior to or independently of the PROJECT governed by this AGREEMENT.


1.4 'BUSINESS DAY' means Monday to Friday from 9.00 a.m. to 5.00 p.m. (CET), except German (Bavarian) public holidays.

I Agree Cancel



Tresos Activation Code Renewal 3 (For versions 17.0.0 and after)

5. From the Windows start menu, start EB Client License Administrator




Tresos Activation Code Renewal 4 (For versions 17.0.0 and after)

6. In the dialog box:

- Enter (paste) the new Tresos activation code.
(Note: you must be on line to activate.)
- Click Activate

Tresos is now activated



3B. Download, Install / Renew Tresos with License File (versions before 17)



Install Tresos – Versions before 17.0.0 (1 of 4)

- Go to Product Download for Tresos:
 - Sign in to your account at nxp.com
 - Click the following: Software Licensing and Support
 - Autosar SW – Autosar MCAL
 - Autosar SW – Elektrobit Tresos Studio / Autosar Configuration Tool
 - AUTOSAR Tresos Studio 14.2.1
 - I agree
- Select all files and download to any folder.
Be sure to use “Download Selected Files” which uses the Download Manager or else files will be compressed in the wrong format.
 - Versions before 17.0.0: also download license (versions 17.0.0 and later use activation codes)

Product Download

AUTOSAR Tresos Studio 14.2.1

Files License Keys Notes

Show All Files

<input type="checkbox"/>	+	File Description
<input checked="" type="checkbox"/>	+	Evaluation License
<input checked="" type="checkbox"/>	+	EB_tresos_installation_guide.pdf
<input checked="" type="checkbox"/>	+	STUDIO_14.2.1_2014-01-28.zip
<input checked="" type="checkbox"/>	+	Studio_new_and_noteworthy.pdf
<input checked="" type="checkbox"/>	+	Studio_release_notes.pdf

Download Selected Files


Install Tresos – Versions before 17.0.0 (2 of 4)

- **Unzip** the downloaded Tresos file

- Run **setup.exe**


- Choose unique folder

- Click Install





Install Tresos – Versions before 17.0.0 (3 of 4)

- Start Tresos
- First time: a workspace needs to be created.
 - Click Yes.
- Close Welcome screen
- After several seconds, the License Information window appears
 - Click Licenses..
- Click “+”




Install Tresos – Versions before 17.0.0 (4 of 4)

- Navigate to where you downloaded the Tresos license file (probably with other Tresos installation files from your account)
- Select license file
- Click Open
- Click OK



License File Renewal 1 – Tresos versions before 17.0.0

- Every 3 months the Tresos license file expires
- Customers with an active MCAL license (such as DISM or evaluation), will automatically get a new license file in their account.
- Obtaining new Tresos license:
 - Sign in to your account at nxp.com
 - Click the following: Software Licensing and Support
 - Autosar SW – Autosar MCAL
 - Autosar SW – Elektrobit Tresos Studio / Autosar Configuration Tool
 - Download the most recent license to a file



License File Renewal 2 – Tresos versions before 17.0.0

- Start Tresos
- Go to Help – Licenses
- Select the downloaded license.

4. Download, Install Make utility




Make from GnuWin32 1

- Go to <https://sourceforge.net/projects/getgnuwin32/files/>

- Note – screenshots are done with Windows 7. Windows 10 may differ.

- Click on getgnuwin32





The screenshot shows a web browser window displaying the SourceForge project page for GnuWin32. The browser's address bar shows the URL <https://sourceforge.net/projects/getgnuwin32/files/>. The page features a navigation menu with 'SOURCEFORGE' and a search bar. Below the navigation, there is an advertisement for VMware Integrated OpenStack. The main content area shows the project name 'GnuWin32' with a 'beta' badge and the description 'Free GNUWin32 utility packages'. A navigation bar includes links for 'Summary', 'Files', 'Reviews', 'Support', 'Wiki', 'Tickets', 'News', 'Discussion', and 'Donate'. A link for 'Download GetGnuWin32-0.6.3.exe' is visible. Below this, a file list table is shown with columns for 'Name', 'Modified', 'Size', and 'Downloads / Week'. The table contains one entry: 'getgnuwin32', modified on '2011-05-31', with a size of '1,108' and '1,108' downloads per week. A red arrow points to the 'getgnuwin32' entry in the table.

Name	Modified	Size	Downloads / Week
getgnuwin32	2011-05-31	1,108	1,108

Make from GnuWin32 2

- Click on the recent version



Advertisement

Home / Browse / Business & Enterprise / Office/Business / GnuWin32 / Files

GnuWin32 beta
Free GNUWin32 utility packages
Brought to you by: [michaelis](#)

Summary | **Files** | Reviews | Support | Wiki | Tickets ▾ | News | Discussion | Donate


Looking for the latest version? [Download GetGnuWin32-0.6.3.exe](#)

Home / getgnuwin32

Name ↕	Modified ↕	Size ↕	Downloads / Week ↕
↑ Parent folder			
📁 0.6.30	2016-08-06		1,075
📁 test builds	2014-01-22		1
📁 other	2011-05-31		0
📁 old versions - archival purpos...	2009-11-16		32

Make from GnuWin32 3

- Click on version to download
- Wait for download to complete



The screenshot shows a web browser window displaying the SourceForge project page for GnuWin32. The browser's address bar shows the URL: <https://sourceforge.net/projects/getgnuwin32/file>. The page title is "GnuWin32 beta" and it is described as "Free GNUWin32 utility packages" brought to you by "michaelis".

Navigation tabs include Summary, Files, Reviews, Support, Wiki, Tickets, News, Discussion, and Donate. A link for "Download GetGnuWin32-0.6.3.exe" is visible. The breadcrumb trail is "Home / getgnuwin32 / 0.6.30".


Name	Modified	Size	Downloads / Week
Parent folder			
source	2016-08-06		0
openssl-1.0.2h.zip	2016-08-06	4.3 MB	7
openssl-1.0.2h.sha	2016-08-06	62 Bytes	2
HOWTO_Proxy_Support.txt	2013-04-18	1.1 kB	10
README	2011-09-07	175 Bytes	11
HOWTO_Add_GnuWin32_To_Systeme...	2011-05-29	61.6 kB	19
Release_Notes_0.6.3_amended.txt	2009-11-16	1.7 kB	6
GetGnuWin32-0.6.3.exe	2009-11-16	3.4 MB	1,017
GetGnuWin32-0.6.3.sh			3

Totals: 9 Items | 7.8 MB | 1.075


A red arrow points from the text "Click on version to download" to the "GetGnuWin32-0.6.3.exe" link. A tooltip over the link says "Click to download GetGnuWin32-0.6.3.exe".

Make from GnuWin32 4

- Go to your download file and double click on it to start installation




- Click Accept




Make from GnuWin32 5

- If desired, change GetGnuWin subfolder location. (Steve's default folder is shown)
- Click Install
- A subfolder is created called GetGnuWin32




Make from GnuWin32 6

- Follow instructions to complete installation as shown on the following slides




Make from GnuWin32 7

- Change directory to the subfolder created in your download folder




Make from GnuWin32 8

- Run “download”




Make from GnuWin32 9

- Run install command with proper path (default shown is fine)



Make from GnuWin32 10

- During installation you may get a message that utilities are outdated, and given the opportunity to update.
 - **IMPORTANT: Hit return for every prompt -- anything else may cancel installation**
- The make utilities by default will be in:
C:\gnuwin32\bin



```
Administrator: Command Prompt - install c:\gnuwin32
Would you like more information? [yes]

UnZip 6.00; unzip.exe (2009-04-20) (bugfixes, security fixes)
^ Suggested replacement for GnuWin32 UnZip 5.51 of May 2004

OpenSSL 1.0.2h; all binary files (2016-05-03) (bugfixes, security fixes)
^ Suggested replacement for GnuWin32 OpenSSL 0.9.8h of May 2008

Wget 1.12.1-dev; wget.exe (2010-06-23) (bugfixes, security fixes)
>> No international support, and english help text only.
>> Built from wget mainline 013c8e2f5997 2010-03-04
^^ Suggested replacement for GnuWin32 Wget 1.11.4 of Jun 2008

Bundle of CA Root Certificates; cacert.pem (2016-04-29)
>> Extracted from Mozilla Certificate Authorities list.
^^ Suggested replacement for <unknown>

Sort 7.6 testbuild; sort-7.6.exe (2009-09-11) (bugfixes)
>> Properly supports LC_ALL environment variable. Test build.
^^ Suggested supplement to GnuWin32 Sort 5.3.0 of April 2005


Would you like to install these utilities? [yes]
```

5. Install MCAL (and/or) OS




Install MCAL or OS Software 1

- If you plan to use MCAL, just install MCAL.
 - If you also plan to use OS, then install OS also.
- Double click on the installation SW that you downloaded.
 - Example organization of download folders



- Note: some versions have an installation for MCAL and an installation for the MCAL sample application. Both need to be installed.





Install MCAL or OS Software 3

- A license file is needed. Go back to Product Download Page and click on License Keys tab.
(If logged off, go to nxp.com & sign in ACCOUNT, then click, e.g.: Software Support and Licensing → Automotive SW – Autosar MCAL → Automotive SW – Autosar MCAL → SW574xG-MCAL401-RTMC_SR 1.0.4 → I agree)
- Click on License Keys tab

The image shows a composite of two screenshots. The top-left screenshot is a Windows installer window titled "NXP MPC574XG AUTOSAR 4_0 MCAL RTM 1_0_4 Setup". It displays a "License check" screen for the "NXP MPC574XG AUTOSAR 4_0 MCAL license". The main area contains the text "Please select a license file." and an empty text input field. At the bottom, there are "< Back" and "Next >" buttons. The bottom-right screenshot is the NXP website's "Product Download" page for "SW574XG-MCAL401-RTMC_SR-1". The page has a navigation bar with "PRODUCTS", "APPLICATIONS", and "SUPPORT". A breadcrumb trail reads "NXP > Software & Support > Automotive SW - Autosar MCAL > SW574XG-MCAL401-RTMC_SR-1". On the left, a "Software & Support" menu lists "Product List", "Product Search", "Order History", "Recent Product Releases", and "Recent Updates". On the right, there are tabs for "Files", "License Keys", and "Notes". The "Files" tab is active, showing a "Show All Files" button and a list of files. The file "MPC574XG_MCAL4_0_RTM_1_0_4.exe" is selected with a checkmark. A large red arrow points from the "License Keys" tab in the installer window to the "Files" tab on the website.

Install MCAL or OS Software 4


- If more than one license is shown, find the one that shows an expiration date that is in the future by checking the displayed Expiration Date after generating. Example:
 - Click on one license check box
 - Click on Generate 
 - View expiration date (licenses cannot be generated after expiration date!)



Version Description
1.0.0 SW574XG-MCAL431-RTMC-1.0.0 (View EULA)
1 Available

License Quantity: 1 Expiration Date: Nov 15, 2018

Host ID: ANY
Generated By: Steve Mihalik on Aug 16, 2018



Note: A red arrow points from the 'Generate' button in the previous slide to the 'Expiration Date' field.

License Information

SW574XG-MCAL431-RTMC-1.0.0

Generate

Select All




Item Description MPC574xB-C-G Au
Order Number STEVE-MIHALIK-EVA
Purchase Order Number
Total Number of Licenses: 1

License Applicable to Product(s):

Version	Description
1.0.0	SW574XG-MCAL431-RTMC-1.0.0 (View EULA)

1 Available



Item Description MPC574xB-C-G Au
Order Number SW574XG-MCAL431E
Purchase Order Number
Total Number of Licenses: 2

License Applicable to Product(s):

Version	Description
1.0.0	SW574XG-MCAL431-RTMC-1.0.0 (View EULA)

1 Available

Install MCAL or OS Software 5

- Click “Save All”
- Save generated license to a file.
Suggestions:
 - Provide a common license folder. Example
C:/NXP/AUTOSAR/licenses
 - Choose a name with identification and .dat extension. Example:
license_MPC574xG_MCAL4_3.dat

View Licenses

Below are the licenses you selected to view.

License Overview

Print Friendly

Save All

License Applicable to Product(s):

Version	Description
1.0.0	SW574XG-MCAL431-RTMC-1.0.0

License Quantity: 1

Host ID: ANY

Generated By: Steve Mihalik on Aug 16, 2018

```
#MPC574xB-C-G Autosar 4.3 MCAL (QM)
#SW574XG-MCAL431-RTMC-1.0.0 for Stev
# License for ANY
INCREMENT AUTOSAR_MCAL_MPC574XG metr
9C0 [REDACTED] STRING=S
H [REDACTED] Freescale
ck= [REDACTED] 74367"
```


License Overview

Print Friendly


Save All

Install MCAL or OS Software 5


- Go back to the MCAL installation program and click on the navigate button to locate your license file




- Select your license file
- Click on “Open”




Install MCAL or OS Software 6



- Click Next
- Click Next to install selected components





- Chose destination folder (default shown) and click Next




MCAL Installation only – specify path 7a

- EB Tresos install directory: Click to location where Tresos is installed
- Select proper Tresos directory (If you have multiple “Tresos” folders, select the right one!)
- Click OK
- Click Install
- When done, click Finish



OS Installation only – specify paths 7b

- Browse to and specify required paths. Example:
- GHS 201416 is recommended (it was validated with this version)
- Cygwin is required if using OS Sample Application from OS installation
- Tresos path is mandatory
- Click Install
- Click Finish when done



AUTOSAR OS

- If the OS is to be installed, repeat prior installation steps for OS

6. Sample Application Installation & build Configuration




6A. Sample Application Installation & Configuration MPC574xG **MCAL** **4.0**



MCAL 4.0: Edit sample application launch.bat 1

- Edit the launch.bat file in MCAL's sample application file to provide proper paths for your PC.
- The launch.bat location will be in the sample application folder



MCAL 4.0: Edit sample application launch.bat 2

::TRESOS

SET TRESOS_DIR=C:\EB\tresos14_2_1

::GHS (recommend comp_201416 since MCAL and OS ver 4.0 were tested with it)

SET GHS_DIR=C:\ghs\comp_201714

::DIAB

SET DIAB_DIR=C:/Tools/WindRiver/diab/5.9.4.8

::Path to the plugins folder

SET

PLUGINS_DIR=C:\NXP\AUTOSAR\MPC574XG_MCAL4_0_RTM_1_0_4\eclipse\plugins

SET MAKE_DIR=C:\gnuwin32

::SSC is required when OS is used

::SSC can still be defined if OS is not installed or not defined at all

SET SSC_ROOT=C:\NXP\AUTOSAR\MPC574xG_AUTOSAR_OS_4_0_92_RTM_1_0_3


Example launch.bat changes for NXP S32 Design Studio (gcc like)

- Change MAKE_DIR path:
SET MAKE_DIR=c:/NXP/S32DS_ARM_v2018.R1/utils/msys32/usr
- Change compiler path:
SET LINARO_DIR=C:\NXP\S32DS_ARM_v2018.R1\Cross_Tools\gcc-6.3-arm32-eabi
- Invoke launch.bat with a non-default tool chain. Example: using TOOLchain=linaro. Either:
 - Enter from DOS command prompt
launch.bat TOOLCHAIN=linaro
 - Or create new file with a name like launch_linaro.bat which includes one line:
launch.bat TOOLCHAIN=linaro

MCAL 4.0: Edit sample application launch.bat 3

- **TIP:** Add a **pause** command at the very end of the launch.bat file:

```
ECHO.  
pause  
GOTO end  
  
:end  
pause
```




- Now when you can use launch.bat by double clicking on it from a Windows browser. The batch file executes but after completion it does not automatically immediately exit back to windows. The pause command allows you to see if the make file worked or had errors.
- Note: GHS is the default compiler. If you use a different compiler you must invoke launch.bat a compiler option. Example for WindRiver compiler:
launch.bat TOOLCHAIN=diab

6b. Sample Application Installation & Configuration MPC574xG **MCAL** 4.3




MCAL 4.3: Separate Sample Application Installation

- MCAL 4.3 downloaded software has a separate sample application installation, repeat prior installation steps for it
 - Example of separate installation:



- Example of completed installation of MCAL and sample application.
 - Note Tresos workspaces for different chip versions




MCAL 4.3: MPC574xG Sample Application Initial Structure

Sample Application
Package plugin folder

launch.bat
compiled output

Chip header files
Application code

Documentation




MCAL 4.3: Edit sample application launch.bat 1

The sample application includes a batch file to build the application.

It must be modified for your paths **launch.bat**

- Open launch.bat in the build folder
- Modify path names for your PC (see example on next slide)



MCAL 4.3: Edit sample application launch.bat 2

- Example launch.bat with modified path names and using Green Hills compiler:

```
::TRESOS
```

```
SET TRESOS_DIR=C:\EB\tresos24_0_0
```

```
::GHS
```

```
SET GHS_DIR=C:\ghs\comp_201754
```

```
::DIAB
```

```
::SET DIAB_DIR=C:/Tools/WindRiver/diab/5.9.4.8
```

```
::SET LINARO_DIR
```

```
SET PLUGINS_DIR=C:\NXP\AUTOSAR\MPC574XG_MCAL4_3_RTM_1_0_0\eclipse\plugins
```

```
SET MAKE_DIR=C:\gnuwin32
```

```
::SSC is required when OS is used
```

```
::SSC can still be defined if OS is not installed or not defined at all
```

```
SET SSC_ROOT=C:\NXP\AUTOSAR\MPC574xG_AUTOSAR_OS_4_0_92_RTM_1_0_3
```

```
SET TRESOS_WORKSPACE_DIR= C:\EB\tresos24_0_0\workspace\MPC574XG_MCAL4_3_RTM_1_0_0_Sample_Ap\output
```

Note: this folder name will change
for each Tresos project



Example changes when using NXP S32 Design Studio (gcc like)

- Modify `make\linaro\build_cfg.mak` file by adding the last LDOPT line (in red):

```
LDOPT      := -mcpu=cortex-m4 \  
            -msoft-float \  
            -mthumb \  
            -e _start \  
            -nostartfiles -static -lc -lm -lgcc -lnosys \  
            --sysroot=$(LINARO_DIR)/arm-none-eabi/newlib
```

- Modify `launch.bat`:

- Change MAKE_DIR path:

```
SET MAKE_DIR=c:/NXP/S32DS_ARM_v2018.R1/utils/msys32/usr
```

- Change compiler path:

```
SET LINARO_DIR=C:\NXP\S32DS_ARM_v2018.R1\Cross_Tools\gcc-6.3-arm32-eabi
```

- **Invoke launch.bat using MODE=USER TOOLchain=linaro.** Either:

- Enter from DOS command prompt

```
launch.bat MODE=USER TOOLCHAIN=linaro
```


- Or create new file with a name like `launch_linaro.bat` which includes one line:

```
launch.bat MODE=USER TOOLCHAIN=linaro
```

MCAL 4.3: Edit sample application launch.bat 3

- **TIP:** Add a **pause** command at the very end of the launch.bat file:

```
ECHO.  
pause  
GOTO end  
  
:end  
pause
```



- Now when you can use launch.bat by double clicking on it from a Windows browser. The batch file executes but after completion it does not automatically immediately exit back to windows. The pause command allows you to see if the make file worked or had errors.
- Note: GHS is the default compiler. If you use a different compiler you must invoke launch.bat a compiler option. Example for WindRiver compiler:
launch.bat TOOLCHAIN=diab

7. Additional SW: Compiler, Java




Compiler for MCAL, OS

- NXP's MCAL and OS products are tested using multiple compilers.
 - See the release notes for versions.
- Examples in this presentation are based on MPC574xG MCAL & OS version 4.0.3 using Green Hills Software compiler version 201416.
 - Later versions have not been known to be a problem.
- Obtain and install the compiler if you have not done so.

OS installation only: Java

- If using Autosar OS, a Java version 1.6 or higher is required for the Autosar OS system generator
 - Usually it is already installed in windows
- To determine if Java is installed and the version, go to the DOS command prompt and enter: `java -version`
 - Example:



```
Administrator: Command Prompt
C:\Users\r17052>java -version
java version "1.6.0_29"
Java(TM) SE Runtime Environment (build 1.6.0_29-b11)
Java HotSpot(TM) 64-Bit Server VM (build 20.4-b02, mixed mode)
C:\Users\r17052>
```

- If you do not have version 1.6 or higher, it can be obtained at <https://java.com/en/download/>
 - **Caution:** sometimes installing a new Java version can affect other programs! Suggest not installing it if AUTOSAR OS is not needed.



SECURE CONNECTIONS
FOR A SMARTER WORLD

www.nxp.com