How to rehost CodeWarrior suite licenses

January 2019

SECURE CONNECTIONS
FOR A SMARTER WORLD

1. Go to www.nxp.com and click on "Sign In"

2. Click "Software Licensing and Support"

You logged in at 01-22-2019 14:40:09 MST

🔔 See updates for your followed products at Documentation and Tools Updates > My Updates

👤 PROFILE

- Change My Password
- 2-Factor Authentication (Off)
- Orders
- Subscription Center
- Documentation and Tools Updates

❓ SUPPORT

- View all Communities
- View all Support Methods
- View Existing Issues
  - Ticket begins with 1-XXX or 2-XXX
  - All Other Issues

🔒 SECURE APPLICATIONS

- Cross Check - Part Finder With Pricing
- Cross Check - Competitor Cross Reference
- eCommerce
- MCU Programming Center
- Moderated Downloads
- NXP Secure User Administration
- ROM Programming
- Software Licensing and Support
- My LPCXpresso activations
- NXP Training
- Lead Portal

3. Under the "Product List", select the license you want to rehost.

Software & Support

Product List

Product Search

Order History

Recent Product Releases

Recent Updates

Licensing

License Lists

FAQ

Download Help

Table of Contents

FAQs

Product Information

CodeWarrior Development Suite - Professional

Select a version. To access older versions, click on the " Previous " tab

Current | Previous

Version	Description	Date Available	
10.8.2	CodeWarrior for StarCore 3900FP DSP Eclipse	Dec 6, 2014	Download Log
9.2	CodeWarrior DS for MobileGT Processors, Linux Application Edition (Windows Hosted) WIN	Jan 1, 2011	Download Log
9.2	CodeWarrior Development Studio MobileGT Processor Edition (Windows Hosted) WIN	Jan 1, 2011	Download Log
8.8	CodeWarrior DS for Power Architecture, Linux Application Edition (Windows Hosted) WIN	Jan 1, 2011	Download Log
8.8	CodeWarrior DS for Power Architecture, Linux Platform Edition (Linux Hosted) LINUX	Jan 1, 2011	Download Log
8.8	CodeWarrior DS for Power Architecture, Professional Edition (Windows Hosted) WIN	Jan 1, 2011	Download Log
8.7	CodeWarrior for MPC5XX Full License WIN	Jan 1, 2011	Download Log
8.3	CodeWarrior DS for Freescale 56800/E Hybrid Controllers Standard Edition WIN	Jan 1, 2011	Download Log
7.2	Codewarrior Development Studio, ColdFire Professional Edition WIN	Jan 1, 2011	Download Log
6.3	CodeWarrior for Microcontrollers - Professional Edition	Jan 1, 2011	Download Log
5.1	CodeWarrior for HC12 Professional Edition WIN	Jan 1, 2011	Download Log
3.2	CodeWarrior for Starcore DSP, Windows WIN	Jan 1, 2011	Download Log
3	CodeWarrior Development Studio, 68K Architectures WIN	Jan 1, 2011	Download Log
2.91	CodeWarrior for MPC55xx/MPC56xx - Professional Edition	Jan 1, 2011	Download Log
10.7	CodeWarrior for StarCore 3850 Eclipse	Jan 1, 2011	Download Log
10.6	CodeWarrior for MCU Professional Edition (Windows - Eclipse)	Jan 1, 2011	Download Log
10.4	CodeWarrior for Power Architecture - Professional Edition (Eclipse-Linux hosted)	Jan 1, 2011	Download Log
10.4	CodeWarrior for Power Architecture - Professional Edition (Eclipse-Windows Hosted)	Jan 1, 2011	Download Log
10.2	CodeWarrior for MCU Professional Edition (Linux - Eclipse)	Jan 1, 2011	Download Log
1	PTPH/ePTPH2 Command-Line Compiler	Jan 1, 2011	Download Log

4. Click "I Agree".

Software & Support

Product List

Product Search

Order History

Recent Product Releases

Recent Updates

Licensing

License Lists

FAQ

Download Help

Table of Contents

FAQs

Software Terms and Conditions

CodeWarrior for MCU Professional Edition (Windows - Eclipse)

Please read the following agreement and click "I AGREE" at the bottom before downloading your software.

IMPORTANT. Read the following Freescale Software License Agreement ("Agreement") completely. By any affirming action by you, you indicate that you accept the terms of this Agreement and you also acknowledge that you have the authority, on behalf of your company, to bind your company to such terms. You may then download or install the file.

FREESCALE SOFTWARE LICENSE AGREEMENT

This is a legal agreement between you (either as an individual or as an authorized representative of your employer) and Freescale Semiconductor, Inc. ("Freescale"). It concerns your rights to use this file and any accompanying written materials (the "Software"). In consideration for Freescale allowing you to access the Software, you are agreeing to be bound by the terms of this Agreement. If you do not agree to all of the terms of this Agreement, do not activate or install the Software. If you change your mind later, stop using the Software and delete all copies of the Software in your possession or control. Any copies of the Software that you have already distributed, where permitted, and do not destroy will continue to be governed by this Agreement. Your prior use will also continue to be governed by this Agreement.

I Agree   Cancel

CONFIDENTIAL AND PROPRIETARY

5. Choose "License Keys".

6. Select the return button.

CONFIDENTIAL AND PROPRIETARY

7. If done correctly a "License has successfully been returned" message appear.

8. Begin to register, click the license to rehost.

Software & Support
Product List
Product Search
Order History
Recent Product Releases
Recent Updates

Licensing
License Lists

FAQ
Download Help
Table of Contents
FAQs

Product Information

CodeWarrior Development Suite - Professional

Select a version. To access older versions, click on the " Previous " tab

Current | Previous

Version	Description	Date Available	
10.8.2	CodeWarrior for StarCore 3900FP DSP Eclipse	Dec 6, 2014	Download Log
9.2	CodeWarrior DS for MobileGT Processors, Linux Application Edition (Windows Hosted) WIN	Jan 1, 2011	Download Log
9.2	CodeWarrior Development Studio MobileGT Processor Edition (Windows Hosted) WIN	Jan 1, 2011	Download Log
8.8	CodeWarrior DS for Power Architecture, Linux Application Edition (Windows Hosted) WIN	Jan 1, 2011	Download Log
8.8	CodeWarrior DS for Power Architecture, Linux Platform Edition (Linux Hosted) LINUX	Jan 1, 2011	Download Log
8.8	CodeWarrior DS for Power Architecture, Professional Edition (Windows Hosted) WIN	Jan 1, 2011	Download Log
8.7	CodeWarrior for MPC5XX Full License WIN	Jan 1, 2011	Download Log
8.3	CodeWarrior DS for Freescale 56800/E Hybrid Controllers Standard Edition WIN	Jan 1, 2011	Download Log
7.2	Codewarrior Development Studio, ColdFire Professional Edition WIN	Jan 1, 2011	Download Log
6.3	CodeWarrior for Microcontrollers - Professional Edition	Jan 1, 2011	Download Log
5.1	CodeWarrior for HC12 Professional Edition WIN	Jan 1, 2011	Download Log
3.2	CodeWarrior for Starcore DSP, Windows WIN	Jan 1, 2011	Download Log
3	CodeWarrior Development Studio, 68K Architectures WIN	Jan 1, 2011	Download Log
2.91	CodeWarrior for MPC55xx/MPC56xx - Professional Edition	Jan 1, 2011	Download Log
10.7	CodeWarrior for StarCore 3850 Eclipse	Jan 1, 2011	Download Log
10.6	CodeWarrior for MCU Professional Edition (Windows - Eclipse)	Jan 1, 2011	Download Log
10.4	CodeWarrior for Power Architecture - Professional Edition (Eclipse-Linux hosted)	Jan 1, 2011	Download Log
10.4	CodeWarrior for Power Architecture - Professional Edition (Eclipse-Windows Hosted)	Jan 1, 2011	Download Log
10.2	CodeWarrior for MCU Professional Edition (Linux - Eclipse)	Jan 1, 2011	Download Log
1	PTPu/PTPu2 Command Line Compiler	Jan 1, 2011	Download Log

9. Choose License Keys.

CONFIDENTIAL AND PROPRIETARY

10. Click the "Generate" button.

Software & Support

Product List

Product Search

Order History

Recent Product Releases

Recent Updates

Licensing

License Lists

FAQ

Download Help

Table of Contents

FAQs

License Information

CodeWarrior for MCU Professional Edition (Windows - Eclipse)

Generate

Item Description	CodeWarrior Development Suite - Professional Edition, Perpetual Model, Node-locked License
Order Number	████████████
Purchase Order Number	409433
Total Number of Licenses:	1

☑

License Applicable to Product(s):

Version	Description
10.6	CodeWarrior for MCU Professional Edition (Windows - Eclipse) (View EULA)
	1 Available

Generate

NXP

11. Enter your host ID information.

- (1)If you are using a Node-Lock License you will be required to enter your Disk Serial Number, Ethernet MAC address or Dongle FlexID. You can get host details from your system running CMD with the commands "VOL" for Disk Serial num(8 digits) Or "ipconfig /all" for Ethernet MAC.

- (2)For floating license enter your server Disk Serial Num or Ethernet address plus the name or IP address.

12. Click the "Generate" button.

Software & Support

Product List

Product Search

Order History

Recent Product Releases

Recent Updates

Licensing

License Lists

FAQ

Download Help

Table of Contents

FAQs

Generate Licenses

You can get the host details of your system running CMD with the commands "vol" for Disk Serial num (8 digits) or "ipconfig /all" for Ethernet MAC.

	Number of Licenses Available
License Applicable to Product(s):	
Version Description	1
10.6 CodeWarrior for MCU Professional Edition (Windows - Eclipse)	

Node Host ID	Disk Serial Number ▾ ████████
Name	

Generate

NXP

13. Click "Save all".

14. Save the license.dat file to the installation directory of CodeWarrior.

- (1)For Node-Lock License , it's done.

- (2)For Floating License , please refer " Floating License Installation Guide for Windows"
(https://www.nxp.com/docs/en/brochure/FLTLICINSTWINBR.pdf)

SECURE CONNECTIONS
FOR A SMARTER WORLD