

LPC54608 IAR EWARM debug circuit

I wrote IAR EWARM debug circuit of LPC54608.
I use 10 pins connector.

If there is a mistake, please point out.

If there is a circuit which isn't enough,
Please point out.

SWDIO is connected to M3(P0,12)
SWCLK is connected to L3(P0,11)
SWO is connected to P2(P0,10)

