



PB0 GPIO16	ENL	1	2	PB1 GPIO17	ENR
PB2 GPIO18		3	4	PB3 GPIO19	
PB4 ANP0	AD0	5	6	PB5 ANP1	AD1
PB6 ANP2	AD2	7	8	PB7 ANP3	AD3
PB8 ANS0	AD4	9	10	PB9 ANS1	AD5
PB10 ANS2	AD6	11	12	PB11 ANS3	AD7
PB12 EOUC4	PWM_SERVO	13	14	PB13 EOUC5	SCLK
PB14 EOUC6	PWML	15	16	PB15 EOUC7	PWMR