# i.MX Android<sup>™</sup> Extended Codec Release Notes

# **1** Release Description

The features described in the release notes are supported by Freescale implemented media framework OMXPlayer. They are only available after installing the android\_L5.0.0\_1.0.0-ga\_omxplayer\_source.tar.gz software package.

Only codecs that have no license restrictions are included in OMXPlayer package.

Codecs that have license restrictions are provided in separate packages. Further details are provided in Section 6.

### 2 Supported Hardware SoCs/ Boards

- i.MX 6Quad SABRE-SD board and platform
- i.MX 6DualLite SABRE-SD platform
- i.MX 6Quad SABRE-AI platform
- i.MX 6DualLite SABRE-AI platform
- i.MX 6SX SABRE-SD platform
- i.MX 6SoloLite EVK platform

# 3 What's New in This Release

• Enhanced stability and robustness.

© 2015 Freescale Semiconductor, Inc.

#### Contents

1	Release Description	1
2	Supported Hardware SoCs/Boards	1
3	What's New in This Release	1
4	Enhanced Features	2
5	Codec Specification	6
6	License Restricted Codecs	9
7	Extending the Android Multimedia Framework APIs	9
8	How to Install the OMXPlayer Package	. 10
9	Limitations of This Release	. 10
10	Known Issues	. 10



# 4 Enhanced Features

For the i.MX 6Dual/Quad and i.MX 6DualLite, the enhanced features include the following:

- Local Playback
  - Enhanced and extended formats and codecs
  - Trick mode playback
  - Multiple audio track selection
- Recording
- Streaming playback
- Audio pass through
- Subtitle

For the i.MX 6SoloX and i.MX 6SoloLite, the enhanced features include the following:

- Local Playback
  - Enhanced and extended formats and codecs
- HTTP streaming playback

# 4.1 Local playback

This section describes the local playback information.

### 4.1.1 Enhanced and extended formats and codecs

The following table provides the information about the Freescale enhanced codecs.

#### Table 1. Freescale enhanced codecs

File extension Demuxers		Video decoders	Audio decoders
.mp3			MP3
.aac/.adts			AAC LC/PLUS
.wav			LPCM
.flac			FLAC
.amr/.awb			AMR-NB/AMR-WB
.mp4	MP4	MPEG4 SP/ASP except GMC	AAC LC/PLUS
.mov		H.264 BP/MP/HP	MP3
.f4v		H263	Dolby Digital Plus
		MJPEG	
		HEVC	
.m4a	MP4		AAC LC/PLUS
.3gp	MP4	MPEG4 SP/ASP except GMC	AAC LC/PLUS
		H.264 BP/MP/HP	AMR-NB
		H263	AMR-WB
		HEVC	

Table continues on the next page...

File extension	Demuxers	Video decoders	Audio decoders
.avi	AVI	MPEG4 SP/ASP except GMC	AAC LC/PLUS
		Xvid	MP3
		H.264 BP/MP/HP	LPCM
		H263	
		MJPEG	
		HEVC	
.wma	ASF		WMA STD, PRO, Lossless
			Dolby Digital Plus
.wmv/.asf	ASF	VC-1 SP/MP/AP	WMA STD, PRO, Lossless
		WMV 7/8	
		HEVC	
.mkv/mka	MKV	H.264 BP/MP/HP	AAC
		MPEG4 SP/ASP except GMC	MP3
		Xvid	WMA STD, PRO, Lossless
		VC-1 SP/MP/AP	Vorbis
		HEVC	Dolby Digital Plus
			Opus
.flv/.f4v	FLV	Sorenson H263	MP3
		H.264 BP/MP/HP	AAC
.mpg	MPEG2/PS	MPEG2 BP/MP	MP3
.vob	MPEG2/TS	MPEG2 BP/MP	AAC
.ts		H.264 BP/MP/HP	AC3
.m2ts			LPCM
			Dolby Digital Plus
.webm	MKV	VP8	MP3
			AAC LC/PLUS
.rmvb	RM	RV 8/9/10	RA
			AAC
.rm	RM	RV 8/9/10	RA
			AAC
.ra	RM	-	RA

#### Table 1. Freescale enhanced codecs (continued)

#### NOTE

- AACPLUS is provided as a separate standard codec package.
- AC3, ASF, WMV, WMA, DDPlus, and RMVB are restricted codec packages and are not generally available. The user should install them from the Restricted Codec Package.
- MJPEG subtypes, MJPEG\_2000, and MJPEG\_B are not supported.
- MJPEG only supports YUV420 and YUV422 (horizontal) color formats.

### 4.1.2 Trick mode playback

Trick mode playback is supported by the extended API setPlaySpeed(int[] Speed).

- 0 < Speed[0] < 2: This is slow playback, video played with audio.
- -16 <= Speed[0] <= -2: This is fast backward, audio is muted and shows video key frames with selected speed.
- $2 \le \text{Speed}[0] \le 16$ : This is fast forward, audio is muted and shows video key frames with selected speed.
- Result speed is stored in Speed[0]. Check whether this call succeeds or fails.

#### 4.1.3 Multiple audio track selection

Audio track section is supported if the file has multiple audio tracks at runtime. For Android<sup>™</sup> Jelly Bean platform or later versions, selection is implemented through MediaPlayer::selectTrack API.

### 4.2 Recording

The following table provides the information about recording.

File extension	Video encoders	Audio encoders
.3gp	H263	AMR-NB
	H264	AMR-WB
	MPEG4	AAC LC
.mp4	H263	MP3
	H264	AAC LC
	MPEG4	

 Table 2.
 Feature matrix for recording

#### NOTE

- All video codecs are accelerated with the Video Processing Unit (VPU).
- AMR-NB, AMR-WB, and MP3 encoder are optimized by Freescale.
- AAC LC encoder is from Google native encoder.

### 4.3 Streaming playback

The following table provides the information about streaming playback.

#### Table 3. Feature matrix for streaming playback

Protocol	File format
НТТР	.mp4/.3gp/.mov
	.flv/ .f4v
	.avi
	.wmv/.asf

Table continues on the next page...

i.MX Android™ Extended Codec Release Notes, Rev. L5.0.0\_1.0.0-ga, 06/2015

Protocol	File format
	.mpg/.vob/.ts
	.mp3
	.aac
	.wma
	.mkv
RTSP	.mp4
RTP	.ts
UDP	.ts

#### Table 3. Feature matrix for streaming playback (continued)

To set up RTP/UDP streaming, perform the following operations:

- Install vlc 1.1.5 on Windows® OS or Ubuntu.
- For the UDP streaming server: run vlc with the command:

vlc -vvv stream\_file\_name --sout udp://224.0.1.1:1234

- For the RTP streaming server:
  - a. Start vlc with the GUI, and select MediaStreaming.
  - b. Press Add to load the stream file, press Stream, and click Next.
  - c. Select RTP/Mpeg Transport Stream from the drop-down list, and click Add.
  - d. Enter the IP address 224.0.1.1 and base port number 5004, and deselect Activate Transcoding.
  - e. Press Stream at the bottom. The server is started.
- For the UDP streaming client, run Gallery on the Android platform with the command:

```
am start -n com.android.gallery3d/com.android.gallery3d.app.MovieActivity -d udp://
224.0.1.1:1234
```

• For the RTP streaming client, run Gallery on the Android platform with the command:

```
am start -n com.android.gallery3d/com.android.gallery3d.app.MovieActivity -d rtp://
224.0.1.1:5004
```

• For the uni-cast, use client IP address instead of 224.0.1.1 when starting the server, and use the server IP address instead of 224.0.1.1 when starting the client.

### 4.4 Audio pass through

The following table provides the information on audio pass through.

#### Table 4. Feature matrix for audio pass through

File extension	Audio format
.avi	AC3
.mkv	
.mpg	
.vob	
.ts	

#### **Codec Specification**

The steps to enable or disable the audio pass through feature are given below:

- 1. Boot the board in dual display mode.
- 2. Connect the board with the Audio/Video receiver through the HDMI cable.
- 3. Enter the following commands from the console to enable the audio pass through feature:

```
$ echo 2000 > /data/system/audio_pass_through_pref
```

```
$ chmod 777 /data/system/audio_pass_through_pref
```

4. Enter the following command on the console to disable the audio pass through feature:

```
$ echo 1000 > /data/system/audio_pass_through_pref
```

#### NOTE

The user can also add a check box in Android Settings to enable/disable the audio pass through feature.

### 4.5 Subtitle

The following table provides the information on subtitle.

Туре	Format
In Band	SRT UTF-8
Out Band	SRT UTF-8

# 5 Codec Specification

### 5.1 Video decoder for i.MX 6Quad/Dual/DualLite

Feature	Profile	Max. resolution	Min. resolution	Max. framerate	HW/SW	Bitrate	Comments
MPEG2	MP	1920 * 1080	64 * 64	30 fps	HW	50 Mbps	-
MPEG4/Xvid	SP	1920 * 1080	64 * 64	30 fps	HW	40 Mbps	-
	ASP	1920 * 1080	64 * 64	30 fps	HW		-
H.263	P3	1920 * 1080	64 *64	30 fps	HW	20 Mbps	-
H.264	BP	1920 * 1080	64 * 64	30 fps	HW	50 Mbps	-
	MP	1920 * 1080	64 * 64	30 fps	HW		-
	HP	1920 * 1080	64 * 64	30 fps	HW	1	-
VC-1	SP	1920 * 1080	64 * 64	30 fps	HW	45 Mbps	-
	MP	1920 * 1080	64 * 64	30 fps	HW		-
	AP	1920 * 1080	64 * 64	30 fps	HW		-
VP8	-	1280 * 720	64 * 64	30 fps	HW	20 Mbps	i.MX 6Quad

 Table 5.
 Video decoder for i.MX 6Quad/Dual/DualLite

Table continues on the next page...

Feature	Profile	Max. resolution	Min. resolution	Max. framerate	HW/SW	Bitrate	Comments
		1920 * 1080	64 * 64	30 fps	HW		i.MX 6DualLite
MJPEG	-	1920 * 1080	64 * 64	30 fps	HW	120 Mpixl/s	-
RV	8/9/10	1920 * 1080	64 * 64	30 fps	H/W	40 Mbps	-
WMV7/8	-	640 * 480	64 * 64	15 fps	SW	-	-
SorensonH26 3	-	720 * 480	64 * 64	30 fps	SW	-	-
VP9	-	720 * 480	64 * 64	30 fps	SW	-	-
HEVC	Main	720 * 480	64 * 64	30 fps	SW	-	-

Table 5. Video decoder for i.MX 6Quad/Dual/DualLite (continued)

# 5.2 Video decoder for i.MX 6SoloX/SoloLite

Feature	Profile	Max. resolution	Min. resolution	Max. framerate	HW/SW	Comments
MPEG4	SP	720 * 480	64 * 64	30 fps	SW	-
	ASP	720 * 480	64 * 64	30 fps	SW	-
H.263	-	720 * 480	64 * 64	30 fps	SW	-
H.264	BP	720 * 480	64 * 64	30 fps	SW	-
	MP	720 * 480	64 * 64	30 fps	SW	-
	HP	720 * 480	64 * 64	30 fps	SW	-
VP8	-	720 * 480	64 * 64	30 fps	SW	-
VP9	-	720 * 480	64 * 64	30 fps	SW	-
HEVC	Main	720 * 480	64 * 64	30 fps	SW	-

#### Table 6. Video encoder for i.MX 6SoloX/SoloLite

# 5.2 Video encoder for i.MX 6Quad/Dual/DualLite

Table 7. Video encoder for i.MX 6Quad/Dual/DualLite

Feature	Profile	Max. resolution	Min. resolution	Max. framerate	HW/SW	Bitrate	Comments
MPEG4	SP	1280 * 720	64 * 64	30 fps	HW	12 Mbps	-
H.263	P3	1280 * 720	64 * 64	30 fps	HW	8 Mbps	-
H.264	BP	1920 * 1080	64 * 64	30 fps	HW	14 Mbps	-

# 5.4 Audio decoder

Encoder	Feature/Profile	Channel	Rate (KHz)	Bitrate	HW/SW	Comments
MP3	MPEG-1 (Layer-1/ Layer-2/Layer-3)	stereo/mono	<=48	8-448	SW	-
	MPEG-2 (Layer-1/ Layer-2/Layer-3)					
	MPEG-2.5 (Layer-3)					
AACLC	MPEG-2 AACLC	<=5.1	8-96	8-256	SW	-
	MPEG-4 AACLC					
HE-AAC	HE-AAC V1	stereo/mono	8-96	Mono: 8-384	SW	-
	HE-AAC V2			stereo:16-768		
WMA10 Std	L1 @ QL1	stereo/mono	44.1	64-161	SW	-
	L2 @ QL1	stereo/mono	<=48	<=161	SW	-
	L3 @ QL1	stereo/mono	<=48	<=385	SW	-
WMA10 Pro	M0a @ QL2	stereo/mono	<=48	48-192	SW	-
	M0b @ QL2	stereo/mono	<=48	<=192	SW	-
	M1 @ QL2	<=5.1	<=48	<=384	SW	-
	M2 @ QL2	<=5.1	<=96	<=768	SW	-
	M3 @ QL2	<=7.1	<=96	<=1500	SW	-
WMA 9 Lossless	N1	stereo/mono	<=48	<=3000	SW	-
	N2	<=5.1	<=96	<=3000	SW	-
	N3	<=7.1	<=96	<=3000	SW	-
AC-3	-	<=5.1	<=48	32-640	SW	-
FLAC	-	<=7.1	8-192	-	N/A	-
DD-plus	-	<=7.1	32, 44.1, 48	<=6.144 Mbps	SW	-
RA	cook	stereo/mono	64, 88.2, 96 8k, 11.025k, 22.05k, 44.1k	-	SW	-

#### Table 8. Audio decoder

# 5.5 Audio encoder

#### Table 9. Audio encoder

Encoder	Feature/Profile	Channel	Rate (KHz)	Bitrate	HW/SW
MP3	MPEG-1/Layer-3	Stereo/Mono	32, 44.1, 48	32k, 48k, 56k, 64k, 80k, 96k, 112k, 128k, 160k, 192k, 224k, 256k, 320k	SW

Table continues on the next page ...

#### i.MX Android™ Extended Codec Release Notes, Rev. L5.0.0\_1.0.0-ga, 06/2015

Encoder	Feature/Profile	Channel	Rate (KHz)	Bitrate	HW/SW
AMR NB	-	-	8	12.2, 10.2, 7.9, 7.4, 6.7, 5.9, 5.15, 4.75	SW
AMR WB	-	-	16	23.85, 23.05, 19.85, 18.25, 15.85, 14.25, 12.65, 8.85, 6.6k	SW

 Table 9. Audio encoder (continued)

### 6 License Restricted Codecs

For information about receiving the restricted codec packages, contact a Freescale representative or visit www.freescale.com/ imxcommunity.

### 6.1 Package list

The following features are supplementary to standard codec release packages.

Package name	Feature
fsl_ac3_dec.tar.gz	Audio Codec: AC3
fsl_ddp_dec.tar.gz	Audio Codec: DD Plus
fsl_ms_codec.tar.gz	Demuxer: ASF     Video Decoder: WMV     Audio Codec: WMA
fsl_real_dec.tar.gz	<ul> <li>Demuxer: RM</li> <li>Video Decoder VPU firmware</li> <li>Audio Decoder: RA</li> </ul>

### 6.2 How to install the license limited codecs

See the readme file of each package.

# 7 Extending the Android Multimedia Framework APIs

```
/* trick mode */
/**
* Set playback speed.
*
* @param Speed[] contains only one item which is normal speed multiplied by 0x10000
* Range of normalized speed is:
*        [-16,-2] means rewind, [0.1, 16] means fast forward, step is 0.1
```

i.MX Android™ Extended Codec Release Notes, Rev. L5.0.0\_1.0.0-ga, 06/2015

#### How to Install the OMXPlayer Package

```
* when normalized speed is [0.1, 1.9] audio is outputted, otherwise audio
```

```
* is not outputted.
```

```
* After this function call returns, result speed is stored in Speed[0], to show whether
it succeeds or fails.
*/
```

```
public native void setPlaySpeed(int[] Speed);
```

### 8 How to Install the OMXPlayer Package

To install the OMXPlayer package, perform the following steps:

- 1. Copy the OMXPlayer package to the Android root directory.
- 2. Go to the Android root directory and decompress the OMXPlayer package.

This step generates device/fsl-codec, external/fsl\_imx\_omx, clean\_obj\_before\_building.sh, and switch\_build\_to.sh.

```
$ source build/envsetup.sh
$ lunch <target build platform> # e.g., sabresd_6dq-user
$./switch_build_to.sh full
$./clean_obj_before_building.sh
$make
```

# 9 Limitations of This Release

- The minimum resolution is 64\*64
- Complex Profile of WMV9 is not supported
- Multimedia files that do not have index table may not be searchable
- · Corrupted multimedia files may not be searchable and may have an incorrect duration

### 10 Known Issues

None.

#### How to Reach Us:

Home Page: freescale.com

Web Support: freescale.com/support Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address: freescale.com/SalesTermsandConditions.

Freescale and the Freescale logo are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners. ARM, ARM Powered logo, and Cortex are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved. © 2015 Freescale Semiconductor, Inc.

Document Number: IMX6ACRN Rev. L5.0.0\_1.0.0-ga 06/2015

